

ARINC 708
Software Tools
Programmer's Reference



Table of Contents

1	Introduction	
	Getting Started	1-2
	Installation.....	1-2
	Assigning a Device Number	1-2
	Overview of the Weather Radar Display Databus	1-3
	ARINC 708 Module	1-4
	ARINC 708 Software Tools Functions	1-5
	ARINC 708 Software Tools for the EXC-4000/8000 Family of Carrier Boards	1-5
	Compiler Options	1-6
	Conventions Used in the Programmer's Reference	1-6
	Technical Support	1-6
2	Initialization Functions	
	Init_Module_708	2-2
	Release_Module_708.....	2-3
	GetHWRev_708.....	2-4
	SetLoopback_708.....	2-4
	GetModuleTimetag_708	2-5
	ModuleTimetagReset_708.....	2-5
	Get_Error_String_708.....	2-6
3	Configuration Functions	
	Event Generation: Status, Interrupts and Output Triggers	3-1
	Channel Status Bit	3-1
	Interrupt/Trigger	3-1
	SetupTransmitChannel_708	3-2
	SetupReceiveChannel_708	3-2
	SetInterrupt_708	3-3
	SetTransmitInterval_708.....	3-3
	SetTrigger_708	3-4
	SetEventFrequency_708	3-4
4	Communication Functions	
	ClearStatus_708	4-1
	GetStatus_708.....	4-2
	NumberWordsInBuffer_708	4-2
	ReadWord_708.....	4-3
	StartReceive_708	4-3
	StartTransmit_708	4-4
	Stop_708	4-4
	WriteWord_708.....	4-5
	ARINC 708 WORD Utility Functions	4-6
	GetData_708	4-6
	SetData_708.....	4-6
	GetPixel_708	4-6
	SetPixel_708.....	4-7

GetControlData_708	4-7
SetControlData_708	4-7

5 Interrupt Functions

Get_Interrupt_Count_708	5-2
InitializeInterrupt_708	5-3
Wait_for_Interrupt_708	5-4
Wait_for Multiple Interrupts_708	5-5

Appendix A ARINC 708 Specifications

Appendix B Flags for Use with *ARINC 708 Software Tools*

Appendix C *ARINC 708 Software Tools* Library

Appendix D Code Index

Appendix E Error Messages

1 Introduction

Chapter 1 provides an overview of the *ARINC 708 Software Tools* and the avionics communication hardware for the Excalibur's ARINC 708 weather radar display databus module on the EXC-4000/8000 family of carrier boards. The module supports the ARINC 708/453 Airborne Weather Radar protocol.

Getting Started	1-2
Installation.....	1-2
Assigning a Device Number	1-2
Overview of the Weather Radar Display Databus	1-3
ARINC 708 Module	1-4
Receive Mode	1-4
Transmit Mode.....	1-4
ARINC 708 Software Tools Functions.....	1-5
<i>ARINC 708 Software Tools</i> for the EXC-4000/8000 Family of Carrier Boards.....	1-5
Compiler Options	1-6
Conventions Used in the Programmer's Reference	1-6
Technical Support.....	1-6

Getting Started

Before starting to write applications:

1. Install your board. For instructions, see **Installation Instructions.pdf** in the root folder of the *Excalibur Installation CD*.
2. Use the *Excalibur Installation CD* to install the software for your board and modules. For instructions, see **Installation Instructions.pdf**.
3. Locate the hardware manual (*User's Manual*) and the software manual (*Programmer's Reference*) on the *Excalibur Installation CD*, for your board and modules.
4. Copy them to your computer.
5. Fill out the registration card and return it to your Excalibur representative.

Note: If anything is missing or damaged, contact your Excalibur representative.

Installation

For hardware and software installation instructions, see **Installation Instructions.pdf** in the root folder of the installation CD. When downloading new software from the Excalibur website, **Installation Instructions.pdf** is contained in the zip file.

The *Excalibur Installation CD* you received with your package is the most recent release of the CD as of the date of shipping. Software and documentation updates can be found and downloaded from our website: www.mil-1553.com.

The standard software provided with Excalibur boards and modules is for Windows operating systems. For more details, see **Installation Instructions.pdf**. Software for other operating systems may be available. Check on our website or write to excalibur@mil-1553.com.

Assigning a Device Number

The ExcConfig utility is used to assign a device number of 0 – 15 to the board, which is used when running Excalibur's *Software Tools*. The first function generally called in an application program is `Init_Module`, and `Init_Module` requires the device number as one of its parameters.

ExcConfig assigns a device number by creating an association between the selected device number and the Unique Identifier of the board. It stores this information in the Windows Registry.

The Unique Identifier is set by a DIP switch or jumpers on the board. (For more details, see your board's user's manual. In the user's manual, the Unique Identifier is called the Selected ID.) For ExpressCard and PCMCIA cards, there are no DIP switches or jumpers for setting the Unique Identifier; the Socket Number is used instead.

Note: When only one board of the same type is installed in your computer, you have the option of using the board's default device number instead of running ExcConfig. However, you cannot use the default device number when you have two or more boards in the computer that have the same default device number, or if your board does not have a default device number. The following table lists the default device numbers for most board types.

Board Type	Default Device Number	#define Value
UNET, RUNET	None – the board's device number must be set via ExcConfig	N/A
VME, VPX	None – the board's device number must be set via a DIP switch (or jumper)	N/A
Ethernet, 664 (AFDX)	34 (dec)	EXC_ETHERNET_PCIE or EXC_664_PCIE
1394	32 (dec)	EXC_1394PCI
MCH	29 (dec)	EXC_1553PCIMCH
All Other Boards in this Manual	25 (dec)	EXC_4000PCI

Overview of the Weather Radar Display Databus

The Weather Radar protocol consists of 1600-bit ARINC 708 words, which, when interpreted and plotted together, form a picture of weather patterns in the surrounding area. The various weather conditions are indicated by the colors displayed.

The picture is formed as follows: emanating from the center of a circle, a single radius line at a time is drawn, where each radius line is the data from a single ARINC 708 word.

Each ARINC 708 word is composed of 64 bits of control information, including the scan angle - the angle at which that line is to be drawn on the circle, and 512 'bins' - each one a 3-bit value specifying the color of a pixel to be drawn along that line.

Scan angle information is stored in the 12 bits between bit 52 (the 52nd bit received) and bit 63. Angle 0 degrees is "dead ahead" (up); angle 90 degrees is "right wing" (to the right). The angle to be used for drawing this line of data is determined by the combination of the 12 bits, which are defined as follows:

Bit	Angle (in degrees)	Bit	Angle (in degrees)
63	180	57	2.8125
62	90	56	1.40625
61	45	55	0.703125
60	22.5	54	0.3415625
59	11.25	53	0.17578125
58	5.625	52	0.087890625

Table 1-1 Scan Angle

The weather conditions represented by the 3-bit pixel data are:

Pixel Value (3 bits)	Weather Condition
0	no precipitation
1	light precipitation
2	moderate precipitation
3	heavy precipitation
4	very heavy precipitation
5	reserved
6	medium turbulence
7	heavy turbulence

Table 1-2 Pixel Values

Some radar displays do not require 512 pixels, they may use only 128 or 256 pixels. Such devices have the option of repeating the data more than once which would allow for data error detection. When less than 512 pixels are used, the actual pixels can occupy the first block of the 'bin' space or, alternatively, the actual pixels may be interleaved with the unused ones.

ARINC 708 Module

The ARINC 708 module contains two ARINC 708/453 channels, each software-selectable as transmit or receive.

Receive Mode

Each incoming ARINC 708 message is composed of 103 16-bit words comprising: two words of Time Tag, 100 words of ARINC 708 data, and a status word. The user sets the receive channel to receive data on the bus. When the user reads a word, the drivers will check if a complete message is available for reading and return it if it is. Each 16-bit word is checked to verify that the expected word type – Time Tag, data or status – was read and the entire ARINC 708 is checked for Manchester errors. Interrupts can be generated upon receipt of a specified number of ARINC 708 words, or upon error condition indicating receive data overrun.

Transmit Mode

Each outgoing ARINC 708 message is composed of ARINC 708 data words. The user can write up to 655 ARINC 708 words to a buffer. The drivers will inform the user if there is no space left on the module for more words, in which case the user should wait until the module empties the buffer by transmitting the data currently in the buffer. The user sets the transmit channel to send data on the bus, continuously, one-shot (only one ARINC 708 word at a time) or retransmit mode (the contents of the buffer are retransmitted over and over until stopped). Interrupts can be generated upon transmission of a specified number of ARINC 708 words, or upon error condition indicating that there is no data to transmit.

For more information about Receive and Transmit modes, see the module's user's manual.

ARINC 708 Software Tools Functions

The *ARINC 708 Software Tools* is a set of 'C' language functions designed to aid users of Excalibur's ARINC 708 module to write test programs. These functions provide access to all of the *ARINC 708 Software Tools* functions in a structured and straightforward programming environment.

ARINC 708 Software Tools is available for Windows 9x/*ME*, NT, 2000 and XP. The Windows functions were written and tested using Microsoft Visual C++.

ARINC 708 Software Tools for the EXC-4000/8000 Family of Carrier Boards

There are numerous modules available for use on the EXC-4000/8000 family carrier board. Various combinations of these modules may be present on the board at one time. One application may access any of the following configurations:

- one module
- multiple modules of the same type located on one board
- multiple modules of the same type located on separate boards
- multiple modules of different types located on one or separate boards

A general-purpose DLL accompanies the ARINC 708 module for each of the EXC-4000/8000 family boards. Depending on the carrier board and compiler used, the names of the files are:

Carrier board	DLL Name
4000PCI	EXC4000MS.DLL
4000VME/VXI	EXCV4000MS.DLL

The functions that operate at the carrier board level are contained in the **EXC4000.c** file for PCI carrier boards and the **EXCV4000.c** file for VME/VXI boards. The function, `Get_4000Module_Type` may be called for each board and module number, to check which, if any, modules are currently available at that location. (This function is also called automatically from `Init_Module_708` to ascertain that the type of module is an ARINC 708 module.) These DLLs are installed automatically in the Windows/System folder when the *Software Tools* are installed for modules.

The function `Select_Time_Tag_Source_4000` sets the Time Tag source for all the modules on the carrier board. The Time Tag source cannot be set for individual modules.

For other functions that operate at the carrier board level see the applicable carrier board's *Programmer's Reference*.

Compiler Options

The DLL is compiled under Microsoft Visual studio using the **_cdecl** calling convention. The driver functions in *ARINC 708 Software Tools* are supplied both in source form and linked as a DLL. When writing application programs, keep in mind that the module is a physical resource, and therefore you cannot run multiple copies of the program simultaneously.

Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for inputs where applicable. All structures and flags used by *ARINC 708 Software Tools* functions are defined in **Appendix B Flags for Use with ARINC 708 Software Tools**.

Functions are written as 'C' functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_708` function. (See **Appendix E: Error Messages**).

In Windows all user-defined programs must include the file **proto_708.h**. This file includes all the necessary header files and **DLL** function prototypes to operate *ARINC 708 Software Tools*.

Conventions Used in the Programmer's Reference

To help differentiate between different kinds of information, the following character styles are used in the *Programmer's Reference*:

Functions look like this.

Variables look like this

Parameter look like this.

File names look like this.

FLAGS look like this

Note: WORD = unsigned short int

Technical Support

Excalibur Systems is ready to assist you with any technical questions you may have. For technical support, visit the [Technical Support](http://www.mil-1553.com/Technical_Support) page of our website (www.mil-1553.com). You can also contact us by phone. To find the location nearest you, visit to the [Contact Us](http://www.mil-1553.com/Contact_Us) page of our website. Before contacting Technical Support, please see [Information Required for Technical Support](http://www.mil-1553.com/Information_Required_for_Technical_Support).

2 Initialization Functions

Chapter 2 contains descriptions of the initialization functions necessary to write test programs for the ARINC 708 module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The flags included in each function are defined in **Appendix B: Flags for Use with ARINC 708 Software Tools**.

The functions described in this chapter are:

- Init_Module_708
- Release_Module_708
- GetHWRev_708
- SetLoopback_708
- GetModuleTimetag_708
- ModuleTimetagReset_708
- Get_Error_String_708

Init_Module_708

Description	Init_Module_708 is the first function the user must call for each ARINC 708 module on each device that is accessed in the application program. Before exiting a program, call Release_Module_708 for each module initialized with Init_Module_708. On PCI[e] carrier boards, Init_Module_708 enables the user to access up to four modules on a single board or any combination of up to 16 modules on four separate boards. On VME/VXI carrier boards, Init_Module_708 enables the user to access up to eight modules on a single board or any combination of up to 108 modules on four separate boards. The function may be called with the SIMULATE argument. If the SIMULATE argument is used, a portion of the memory equal to the size of the board's dual-port RAM is set aside. This area is then initialized with an id and version number for use in testing programs when no module is available. Multiple modules may be simulated. It is possible to have real or SIMULATED modules in one application. On PCI[e] carrier boards up to 17 real or SIMULATED modules may be initialized. On VME/VXI carrier boards up to 109 real or SIMULATED modules may be initialized. More than one module may be SIMULATED simultaneously.	
Syntax	Init_Module_708 (int device_num, int module_num)	
Input parameters	device_num	The device number is the index number of the board set in ExcConfig: 0 - 15
	or	
	SIMULATE	If no module is present
	module_num	The module number of the ARINC 708 module on the board: 0 - 7 (depending on the board)
Note:	If only one board is used, the define value EXC_4000PCI (default device number = 25) can be used instead of a device number. If more than one board is used the programmer must run the ExcConfig utility to set the device number.	
Output parameters	none	
Return Values	eopenkernel	If there was an error opening a device
	emodnum	Invalid module number specified

Init_Module_708 (cont.)

enomodule	If no module present at specified location
ewrngmodule	If module specified on carrier board is not ARINC 708 module
etimeoutreset	If timed out waiting for reset
eboardtoomany	If too many boards initialized
sim_no_mem	If no memory for simulation
enoid	If could not find a module at given device address
devhandle	If successful, the handle to the specified module on the board.

PCI[e]

A valid handle is a positive number ranging from 0–16.

VME/VXI

A valid handle is a positive number ranging from 0–108.

Release_Module_708

Description	Release_Module_708 releases any grabbed resources on a specific module. Call the function for each module initialized with Init_Module_708, before exiting a program. To continue accessing the module, call Init_Module_708.	
Syntax	Release_Module_708 (int devhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
Output Parameters	none	
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	0	If successful

GetHWRev_708

Description	GetHWRev_708 returns the hardware revision number.	
Syntax	GetHWRev_708 (int devhandle, int *hwrev)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
Output Parameters	hwrev	Returns the current FPGA revision level of the module
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	0	If successful

SetLoopback_708

Description	SetLoopback_708 sets up the module to loopback mode, where one channel on the module transmits to the other, internally, without a cable.	
Syntax	SetLoopback_708 (int devhandle, int flag)	
Input parameters	devhandle	The handle designated by Init_Module_708
	flag	ENABLE To set up internal loopback mode DISABLE To disable loopback mode
Output parameters	none	
Return values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	einval	If an illegal value is used as an input
	0	If successful

GetModuleTimetag_708

Description	GetModuleTimetag_708 gets the current value of the running Time Tag on the module.	
Syntax	GetModuleTimetag_708 (int_devhandle, unsigned int *timetag)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	timetag	32-bit Time Tag
Return Values	ebadhandle	If invalid handle specified; must be value returned by Init_Module_708.
	0	If successful

ModuleTimetagReset_708

Description	ModuleTimetagReset_708 sets the value of the running Time Tag on the module to 0.	
Syntax	ModuleTimetagReset_708 (int_devhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	none	
Return Values	ebadhandle	If invalid handle specified; must be value returned by Init_Module_708.
	0	If successful

Get_Error_String_708

Description	Get_Error_String_708 accepts the error of return values from other <i>ARINC 708 Software Tools</i> functions. This function returns the string containing a corresponding error message.	
Syntax	Get_Error_String_708 (int errcode, int errlen, char* errstring)	
Example:	<pre>#define ERRORLEN 255 char ErrorStr[ERRORLEN]; Get_Error_String_708 (errorcode, ERRORLEN, &ErrorStr); printf("error is: %s", ErrorStr);</pre>	
Input Parameters	errcode	The error code returned from a <i>Software Tools</i> call.
	errlen	Maximum length of string to be returned - the message string that contains the corresponding error message
Output Parameters	errorstring	An array of 'errlen' characters, the message string that contains the corresponding error message. In case of bad input, this function returns a string denoting that.
Return Values	0	Always

3 Configuration Functions

Chapter 3 contains descriptions of the configuration functions necessary to write test programs for the ARINC 708 module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The flags included in each function are defined in **Appendix B: Flags for Use with ARINC 708 Software Tools**.

The functions described in this chapter are:

SetupTransmitChannel_708
SetupReceiveChannel_708
SetInterrupt_708
SetTransmitInterval_708
SetTrigger_708
SetEventFrequency_708

Event Generation: Status, Interrupts and Output Triggers

Three events can occur:

- A bit is set in the Channel Status register - the status bits are read by GetStatus_708 and are cleared with ClearStatus_708. (See GetStatus_708 on page 4-2 and ClearStatus_708 on page 4-1)
- An interrupt is generated
- An output trigger is generated

Channel Status Bit

The TXRX status bit is set for a receive channel when a specified number of ARINC 708 words is received by the channel. (See SetEventFrequency_708 on page 3-4)

The TXRX status bit is set for a transmit channel when a specified number of ARINC 708 words is received by the channel (See SetEventFrequency_708 on page 3-4)

The error status bit is set for a receive channel when receiving and the buffer is full – overrun condition.

An error status bit is set for a transmit channel when transmitting in CONTINUOUS or RETRANSMIT mode, and the buffer is empty.

Interrupt/Trigger

An interrupt/trigger is generated when the conditions above are fulfilled, and the interrupt/trigger has been enabled for that condition, for the channel. (See SetInterrupt_708 on page 3-3 and SetTrigger_708 on page 3-4).

SetupTransmitChannel_708

Description	SetupTransmitChannel_708 resets the channel and sets it to transmit.	
Syntax	SetupTransmitChannel_708 (int devhandle, int channel, int *chanhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
	channel	The channel number [0 or 1]
Output Parameters	chanhandle	The handle to the specified channel on the module. This handle is the first parameter in all channel specific functions.
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	etimeoutreset	If timed out waiting for reset.
	einvalchan	If tried to set a channel to an illegal value
	0	If successful

SetupReceiveChannel_708

Description	SetupReceiveChannel_708 resets the channel and sets it to receive.	
Syntax	SetupReceiveChannel_708 (int devhandle, int channel, int *chanhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
	channel	The channel number [0 or 1]
Output Parameters	chanhandle	The handle to the specified channel on the module. This handle is the first parameter in all channel specific functions.
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	etimeoutreset	If timed out waiting for reset.
	einvalchan	If tried to set a channel to an illegal value
	0	If successful

SetInterrupt_708

Description	SetInterrupt_708 sets the condition or conditions under which the module is to generate interrupts for the ARINC 708 module.	
Syntax	SetInterrupt_708 (int chanhandle, WORD interrupt_type)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
	interrupt_type	One or both ORed together: TXRX_INTERRUPT Interrupt after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708. ERROR_INTERRUPT Interrupt when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition <i>or</i> NO_INTERRUPT To disable interrupt generation
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.
	noirqset	If no interrupt allocated
	EINVAL	If an illegal value is used as an input
	0	If successful

SetTransmitInterval_708

Description	SetTransmitInterval_708 sets the interval between the beginning of one ARINC 708 word and the next ARINC 708 word in microseconds.	
Syntax	SetTransmitInterval_708 (int chanhandle, WORD interval_micro)	
	chanhandle	The handle returned by SetupTransmitChannel_708
	interval_micro	1600 – 65535: Interval value in microseconds Default value is 5500
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupTransmitChannel_708.
	EINVAL	If an illegal value is used as an input
	0	If successful

SetTrigger_708

Description	SetTrigger_708 sets the condition or conditions under which the module is to generate an output trigger.	
Syntax	SetTrigger_708 (int chanhandle, WORD trigger_type)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708
	trigger_type	One or both ORed together: TXRX_TRIGGER Trigger after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708. ERROR_TRIGGER Trigger when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition or NO_TRIGGER To disable output triggering
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.
	EINVAL	If an illegal value is used as an input
	0	If successful

SetEventFrequency_708

Description	SetEventFrequency_708 sets the desired number of ARINC 708 words to be transmitted/received either before setting the channel status bit, or generating an interrupt, or an output trigger.	
Syntax	SetEventFrequency_708 (int chanhandle, WORD frequency)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
	frequency	The frequency at which to generate a status bit or interrupt: Default value is 1 Module rev B: Maximum values Transmit 655 Receive 636 Module rev A: values 1 – 80
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.
	EINVAL	If an illegal value is used as an input
	0	If successful

4 Communication Functions

Chapter 4 contains descriptions of the receive and transmit communication functions necessary to write test programs for the ARINC 708 module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The **communication** functions are:

ClearStatus_708	StartReceive_708
GetStatus_708	StartTransmit_708
NumberWordsInBuffer_708	Stop_708
ReadWord_708	WriteWord_708

The **ARINC 708 utility** functions are:

GetData_708	SetControlData_708
SetData_708	GetPixel_708
GetControlData_708	SetPixel_708

See **Appendix B: Flags for Use with ARINC 708 Software Tools** for typedef of control data structure.

ClearStatus_708

Description	Call ClearStatus_708 to clear selected bits of the channel status/ interrupt status for the specified channel.	
Syntax	ClearStatus_708 (int chanhandle, WORD clearflag)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708.
	clearflag	One <i>or</i> both ORed together: TXRX_STATUS Clears the bits indicating ARINC 708 words transmitted/received ERROR_STATUS Clears bits indicating error condition <i>or</i> ALL_STATUS Clear all status bits
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708.
	EINVAL	If an illegal value is used as an input
	0	If successful

GetStatus_708

Description	Call GetStatus_708 to read the channel status for the specified channel. This value can be used to ascertain for which channel an interrupt or trigger was generated, and the type of event – TXRX or ERROR.	
Syntax	GetStatus_708 (int chanhandle, int statusflag)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
Output Parameters	statusflag	One <i>or</i> both ORed together TXRX_STATUS The number of ARINC 708 words set in SetEventFrequency_708 was transmitted/received ERROR_STATUS Error occurred on channel <i>or</i> NO_STATUS No channel status set
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.
	0	If successful

NumberWordsInBuffer_708

Description	NumberWordsInBuffer_708 returns the number of words currently in the buffer for the specified channel.	
Syntax	NumberWordsInBuffer_708 (int chanhandle, int *numwords)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708.
Output Parameters	numwords	Number of words currently in the buffer returned for the specific channel. Values: 0 – 65536
Return Values	ebadhandle	If an invalid handle was specified; should be value returned by Init_Module_708
	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708.
	0	If successful

ReadWord_708

Description	ReadWord_708 reads one ARINC 708 word from the buffer for the specified receive channel.	
Syntax	ReadWord_708 (int chanhandle, WORD *wordarray, DWORD *timetag, WORD *wordstatus)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708.
Output Parameters	wordarray	Pointer to 100 WORDs containing one ARINC 708 word
	timetag	A 32-bit Time Tag
	wordstatus	INVALID_708WORD Manchester error
		VALID_708WORD Valid 708 word
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708.
	echantype	If channel type is not receive
	ebadformat	If no proper ARINC 708 word found in receive buffer
	enorcword	If no ARINC 708 word was received
	0	If successful

StartReceive_708

Description	Call StartReceive_708 to start receiving data in the buffer for the specified channel.	
Syntax	StartReceive_708 (int chanhandle)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupReceiveChannel_708 is used.
	echantype	If channel type is not receive
	0	If successful

StartTransmit_708

Description	Call StartTransmit_708 to start transmitting data in the buffer for the specified transmit channel.	
Syntax	StartTransmit_708 (int chanhandle, int duration)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708
	duration	DUR_ONESHOT To send out one ARINC 708 word DUR_CONTINUOUS To continuously transmit until transmit buffer is empty - buffer can be written to continuously DUR_RETRANSMIT To transmit contents of a buffer again and again until stopped - data <i>cannot</i> be written to the buffer
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupTransmitChannel_708 is used.
	echantype	If channel type is not transmit
	EINVAL	If an invalid value was used as an input
	ERUNNING	If channel already running
	0	If successful

Stop_708

Description	Call Stop_708 to stop transmitting/receiving data in the buffer for the specified channel.	
Syntax	Stop_708 (int chanhandle)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupReceiveChannel_708 or SetupTransmitChannel_708 is used.
	0	If successful

WriteWord_708

Description	WriteWord_708 writes one ARINC 708 word to the buffer for the specified channel.	
Syntax	WriteWord_708 (int chanhandle, WORD *wordarray)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708
	wordarray	Pointer to 100 WORDs containing one ARINC 708 word
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupTransmitChannel_708 is used.
	echantype	If function invalid for this channel type
	eoneshot	Cannot write to buffer when channel running in ONESHOT mode
	eretransmit	Cannot write to buffer when channel running in RETRANSMIT mode
	enoxmtword	If no room to transmit ARINC 708 word
	0	If successful

ARINC 708 WORD Utility Functions

See **Appendix B: Flags for Use with ARINC 708 Software Tools** for typedef of control data structure.

GetData_708

Description	GetData_708 reads control data and all pixel information from ARINC 708 word into structures
Syntax	GetData_708 (WORD *wordarray, t_controlData *controlData, WORD *pixelarray)
Input Parameters	wordarray Array containing one ARINC 708 word
Output Parameters	controlData Structure containing control data pixelarray Array of 512 WORDs, one for each pixel's data
Return Values	0 Always

SetData_708

Description	SetData_708 writes control data and all pixel information from structures into an ARINC 708 word.
Syntax	SetData_708 (t_controlData *controlData, WORD *pixelarray, WORD *wordarray)
Input Parameters	controlData Structure containing control data pixelarray Array of 512 WORDs, one for each pixel's data
Output Parameters	wordarray Array containing one ARINC 708 word
Return Values	0 Always

GetPixel_708

Description	GetPixel_708 reads a specific pixel from the data portion of the ARINC 708 word.
Syntax	GetPixel_708 (WORD *wordarray, int pixnum, WORD *pixel)
Input Parameters	wordarray Array of 100 WORDs containing one ARINC 708 word pixnum Pixel number: a value 1 – 512
Output Parameters	pixel One WORD. Pixel data is in the lowest 3 bits
Return Values	EINVAL If an illegal value is used as an input 0 If successful

SetPixel_708

Description	SetPixel_708 writes a specific pixel to the data portion of the ARINC 708 word.	
Syntax	SetPixel_708 (WORD *wordarray, int pixnum, WORD *pixel)	
Input Parameters	wordarray	Array of 100 WORDs containing one ARINC 708 word
	pixnum	Pixel number: a value 1 – 512
	pixel	One WORD. Pixel data is in the lowest 3 bits
Output Parameters	wordarray	The updated array of 100 WORDs containing one ARINC 708 word
Return Values	EINVAL	If an invalid value was used as an input
	0	If successful

GetControlData_708

Description	Call GetControlData_708 to read the control data portion from the ARINC 708 word array into a structure.	
Syntax	GetControlData_708 (WORD *wordarray, t_ControlData *controlData)	
Input Parameters	wordarray	Array of 100 words containing one ARINC 708 word
Output Parameters	controlData	Structure containing control data
Return Values	0	Always

SetControlData_708

Description	Call SetControlData_708 to add control data information into an ARINC 708 word.	
Syntax	SetControlData_708 (t_controlStruct controlStruct, WORD *wordarray)	
Input Parameters	wordarray	Array of 100 words containing one ARINC 708 word
	controlStruct	Structure containing various parts of the Control data
Output Parameters	wordarray	The updated array of 100 words containing one ARINC 708 word.
Return Values	0	Always

5 Interrupt Functions

When writing a Windows program that processes interrupts, a separate thread is generally created to handle the interrupt processing. This thread calls `Wait_for_Interrupt_708`, in order to wait for the next interrupt. When the function returns, the interrupt is processed as needed. This method is demonstrated in the test program **demo_708_int.c** which is included with the *ARINC 708 Software Tools*.

Note: There is no need to reset the physical interrupt line in the interrupt thread; this is handled internally.

In cases of very high interrupt frequency, several interrupts may occur before the interrupt thread resumes execution. The `Get_Interrupt_Count_708` function may be used to determine if multiple interrupts have occurred. Conversely, it is possible that the `Wait_for_Interrupt_708` function will indicate an interrupt that has already been processed by the thread. (This will occur in the case where a subsequent interrupt occurs in between the return of the `Wait_for_Interrupt_708` function and the call to `Get_Interrupt_Count_708`.) Once again, the `Get_Interrupt_Count_708` function may be used to determine if the interrupt has already been processed.

The following functions are described in this chapter:

- `Get_Interrupt_Count_708`
- `InitializeInterrupt_708`
- `Wait_for_Interrupt_708`
- `Wait_for Multiple_Interrupts_708`

The flags included in each function are defined in **Appendix B: Flags for Use with ARINC 708 Software Tools**.

Get_Interrupt_Count_708

Description	Get_Interrupt_Count_708 returns the total interrupt count for the specified module from the time the module was initialized with Init_Module_708.	
Syntax	Get_Interrupt_Count_708 (int devhandle, unsigned long *pdwInterruptCount)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	pdwInterruptCount	Pointer to an unsigned long which receives the interrupt count
Return Values	ebadhandle	If an invalid handle was specified; should be value returned by Init_Module_708
	egetintcount	If there was a kernel error
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparameter	If input parameter is invalid
	ekernelbadpointer	If output parameter buffer is invalid
	ekerneldevicenotopen	If specified device has not been opened
	0	If successful

InitializeInterrupt_708

Description	InitializeInterrupt_708 may be called to initialize interrupt handling for the given module/card. In general, it is not necessary to call this function since the Wait_for_Interrupt_708 function initializes the interrupt handling automatically when it is first called. However, in certain situations, such as a program in which the Wait_for_Interrupt_708 function is not run in a separate thread but is executed sequentially in the main thread, one may wish to initialize the interrupt handling before calling Wait_for_Interrupt_708. Thus, if an interrupt occurs after the initialization but before the call to Wait_for_Interrupt_708, the latter call will return immediately, reporting the interrupt which occurred previously.	
Syntax	InitializationInterrupt_708 (int devhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	none	
Return Values	ebadhandle	If an invalid handle is specified; should be value returned by Init_Module_708
	egetevenhandle1	If there is an error in kernel function Get_Event_Handle, first part
	egetevenhandle2	If there is an error in kernel function Get_Event_Handle, second part
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If specified device was not opened
	0	If successful

Wait_for_Interrupt_708

Description	Wait_For_Interrupt_708 waits for an interrupt on the module. It suspends control of the calling thread while waiting, and returns control to the thread upon receipt of the interrupt, or upon expiration of the time out. If timeout is set to INFINITE, then the call will return only upon receipt of the interrupt.	
Syntax	Wait_For_Interrupt_708(int devhandle, unsigned int timeout)	
Example	Since this function suspends execution of the calling thread, it is generally called from a separate thread, to allow the main thread to continue its processing. An example of a thread routine which waits for interrupts and processes them as they come in is as follows: <pre> DWORD InterruptThread(int referenceParam) { while (1) { int status; status = Wait_For_Interrupt_708(devhandle, INFINITE); if (status < 0) { // We don't check for ekerneltimeout since we passed // in a timeout value of INFINITE. // All other return values indicate error. // Process error... ExitThread(1); } // Process interrupt... // Check total number of interrupts Get_Interrupt_Count_708(devhandle, &numints); } } </pre>	
Input Parameters	devhandle	The handle designated by Init_Module_708
	timeout	Timeout is specified in milliseconds, or INFINITE
Output Parameters	none	
Return Values	ebadhandle	If an invalid handle is specified; should be value returned by Init_Module_708
	egetevenhandle1	If there is an error in kernel function Get_Event_Handle, first part
	egetevenhandle2	If there is an error in kernel function Get_Event_Handle, second part
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If specified device was not opened
	Successful if <i>either</i> :	
	ekerneltimeout	The wait timed out without receiving an interrupt <i>or</i>
	0	If successful

Wait_for Multiple_Interrupts_708

Description	Wait_for_Multiple_Interrupts_708 waits for an interrupt on any of the specified modules. It suspends control of the calling thread while waiting, and returns control to the thread either upon receipt of the interrupt, or upon expiration of the time out. If <code>timeout</code> is set to INFINITE, then the call will return only upon receipt of the interrupt.	
Syntax	Wait_for_Multiple_Interrupts_708 (int nummodules, int *devhandle_array, unsigned int timeout, unsigned long *pdw_Interrupt_Bitfield)	
Input Parameters	nummodules	Number of modules in the devhandle_array
	devhandle_array	An array of module handles
	timeout	Timeout is specified in milliseconds, or INFINITE
Output Parameters	pdw_Interrupt_Bitfield	Pointer to an unsigned long which receives a bit field indicating which of the modules have interrupted (note that more than one module may have interrupted simultaneously). The modules are distributed in the bit field such that the lowest bit corresponds to the first module in the devhandle_array, and so on.
Return Values	egeteventhand1	If there is an error in kernel function Get_Event_Handle, first part
	egeteventhand2	If there is an error in kernel function Get_Event_Handle, second part
	ebadhandle	If an invalid handle specified in the devhandle_array; should be values returned by Init_Module_708.
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If the specified device was not opened
	ekernelbadpointer	If output parameter buffer is invalid
	ekerneltimeout	Successful if <i>either</i> : The wait timed out without receiving an interrupt <i>or</i>
	0	If successful

Appendix A ARINC 708 Specifications

Display Data Bus Format

Bits	Data Display	Function details	On page
01– 08	Label		
09 – 10	Control/Accept	Table A-2 Control Accept Functions	A-2
11	Slave	1 = Slave 0 = Master (Normal)	
12 – 13	Spare		
14	Turbulence Alert	Automatic sensing of a Turbulence alert has occurred	
15	Weather Alert	Automatic sensing of a reflectivity Weather alert has occurred	
16	AntiClutter	Clutter elimination circuitry is in operation	
17	Sector Scan	Reduced Sector scan is in operation	
18	Stability Limits	Aircraft attitude and /or tilt control exceeds the system's design limits.	
19	Cooling Fault		
20	Display Fault		
21	Calibration (T-R) Fault		
22	Altitude input Fault		
23	Control Fault		
24	Antenna Fault		
25	Transmitter/ receiver Fault		
26	Stabilization On		
27 – 29	Mode	Table A-3 Operating mode	A-2
30 – 36	Tilt	Table A-4 Tilt data	A-2
37 – 42	Gain	Table A-5 Gain data	A-3
43 – 48	Range	Table A-6 Range Data	A-3
49	Spare		
50 – 51	Data Accept	Table A-7 Data accept	A-3
52 – 63	Scan Angle	Table A-8 Scan angle	A-3
64	Spare		
65 – 67	Bin 1		
.	.		
.	.	Table A-9 Weather Condition / Reflectivity Data	A-4
.	.		
1598 – 1600	Bin 512		

Table A-1 Display Data Bus Format

Note: The lowest order bit is referred to as bit 1.

Control Accept Function

Matrix Code	Bit 10	Bit 9	Function
0	0	0	Do not accept control
1	0	1	IND 1 accept control
2	1	0	IND 2 accept control
3	1	1	All INDs accept control

Table A-2 Control Accept Functions**Operating Mode**

Matrix Code	Bit 29	Bit 28	Bit 27	Operating Mode
0	0	0	0	Standby
1	0	0	1	Weather [only]
2	0	1	0	Map
3	0	1	1	Contour
4	1	0	0	Test
5	1	0	1	Turbulence [only]
6	1	1	0	Weather & turbulence
7	1	1	1	Reserved [Calibration annunciation]

Table A-3 Operating mode

Note: Weather (only)	Reflectivity (Weather) only data should be transmitted on all azimuth addresses.
Turbulence (only)	Turbulence only data should be transmitted on all azimuth addresses.
Weather & turbulence	Turbulence data combined with reflectivity data is allowed as a means to transmit both weather only and weather plus turbulence words when Weather & turbulence mode is selected.

Tilt Data

Bit	Tilt in degrees
36	-16
35	+8
34	+4
33	+2
32	+1
31	+0.5
30	+0.25

Table A-4 Tilt data**Note:** TWO's complement tilt

Gain Data

Bit	42	41	40	39	38	37	
	1	1	1	1	1	1	Cal
	0	0	0	0	0	0	Max
	0	0	0	1	0	1	-5
	0	0	1	0	1	1	-11
	1	1	1	1	1	0	-62

Table A-5 Gain data**Range Data**

Bit	48	47	46	45	44	43	
	0	0	0	0	0	1	5 NM
	0	0	0	0	1	0	10
	0	0	0	1	0	0	20
	0	0	1	0	0	0	40
	0	1	0	0	0	0	80
	1	0	0	0	0	0	160
	1	1	1	1	1	1	315
	0	0	0	0	0	0	320

Table A-6 Range Data**Data Accept**

Bit	51	50	Function
	0	0	Do not accept data
	0	1	Accept data 1
	1	0	Accept data 2
	1	1	Accept any data

Table A-7 Data accept**Scan Angle**

Bit	Angle (in degrees)	Bit	Angle (in degrees)
63	180	57	2.8125
62	90	56	1.40625
61	45	55	0.703125
60	22.5	54	0.3415625
59	11.25	53	0.17578125
58	5.625	52	0.087890625

Table A-8 Scan angle

Weather Conditions/Reflectivity Data

Matrix code [Pixel Value 3 bits]	Weather Condition	Bin 1		
		Bit 67	Bit 66	Bit 65
0	No precipitation [< Z2]	0	0	0
1	Light precipitation [Z2 - Z3]	0	0	1
2	Moderate precipitation [Z3 - Z4]	0	1	0
3	Heavy precipitation [Z4 to Z5]	0	1	1
4	Very heavy precipitation [> Z5]	1	0	0
5	Reserved ¹	1	0	1
6	Medium turbulence	1	1	0
7	Heavy turbulence	1	1	1

Table A-9 Weather Condition / Reflectivity Data

1. Out of Calibration Indication

Appendix B Flags for Use with *ARINC 708 Software Tools*

Flags are grouped according to the functions in which they are used. Some flags are used in more than one function, and they are duplicated in each section for clarity. Most flags are input parameters. Others are listed for the convenience of the programmer.

Note: Always use flags where provided, rather than the value associated with it, since values may change. For example, use `SIMULATE` with `Init_Module` rather than `0xFFFF`.

The flags are grouped by function.

Init_Module

<code>SIMULATE</code>	<code>0xFFFF</code>	Test drivers without a module present
<code>EXC_4000PCI</code>		If only one board is used, the define value <code>EXC_4000PCI</code> can be used instead of a device number

Create/ParseControlData_708

```
typedef struct
{
    WORD    label; //8 bits
    WORD    controlAccept; //2
    BOOL    slave;
    BOOL    turbulenceAlert;
    BOOL    weatherAlert;
    BOOL    antiClutter;
    BOOL    sectorScan;
    BOOL    stabilityLimits;
    BOOL    coolingFault
    BOOL    displayFault;
    BOOL    calibrationFault;
    BOOL    attitudeFault;
    BOOL    controlFault;
    BOOL    antennaFault;
    BOOL    txRcvFault;
    BOOL    stabilization;
    WORD    operatingMode; //3
    WORD    tilt; //7
    WORD    gain; //6
    WORD    range; //6
    WORD    dataAccept; //2
    WORD    scanAngle; //12
}t_controlStruct;
```

StartTransmit_708

<code>DUR_ONESHOT</code>	<code>0</code>	To send out one ARINC 708 word
<code>DUR_CONTINUOUS</code>	<code>1</code>	To continuously transmit until buffer empty
<code>DUR_RETRANSMIT</code>	<code>2</code>	To transmit contents of buffer again and again until stopped - data <i>cannot</i> be written to the buffer

GetStatus_708

ERROR_STATUS	1	Error occurred on channel
TXRX_STATUS	2	The number of ARINC 708 words set in SetEventFrequency_708 was transmitted/received
NO_STATUS	0	No channel status bits set

ClearStatus_708

ERROR_STATUS	1	Clear error status bit
TXRX_STATUS	2	Clear TXRX status bit
ALL_STATUS	3	Clear all status bits

SetInterrupt_708

ERROR_INTERRUPT	1	Interrupt when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition
TXRX_INTERRUPT	2	Interrupt after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708.
NO_INTERRUPT	0	Disable Interrupts

SetTrigger_708

ERROR_TRIGGER	1	Trigger when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition
TXRX_TRIGGER	2	Trigger after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708.
NO_TRIGGER	0	Disable output triggering

SetLoopback_708

DISABLE	0	Disable loopback mode
ENABLE	1	Set up internal loopback mode

ReadWord_708

INVALID_708WORD	0	Manchester error
VALID_708WORD	1	Valid ARINC 708 word

Module type for EXC-4000/8000 carrier boards

EXC4000_MODTYPE_708	7	A 708 module is present
---------------------	---	-------------------------

Appendix C *ARINC 708 Software Tools Library*

Appendix C includes a list of the files in the Excalibur *ARINC 708 Software Tools* needed to write user-defined applications. The files are divided into three categories:

Source code and Header files for the *ARINC 708 Software Tools* functions. Header files should be included in application programs as needed.

File Extension	Description
*.c	source code
*.h	header file

DLL and associated *.lib files

File Extension	Description
*MS.dll	Microsoft compiler DLL
*MS.dll	Index file used to create applications using Microsoft DLL functions

Demo Programs are examples of programs using *ARINC 708 Software Tools*. They can be used as a basis for user-defined programs. Demo programs include the following types of files.

File Extension	Description
*.c, *.h	Demo source code
*.exe	Demo executable files
*.sln *.suo	Microsoft project solution files

	File Name	Description
Source Code Files	config_708	Functions for configuring ARINC 708 channels
	comm_708	Functions for communication over an ARINC 708 module
	deviceio_708	Functions for interaction with kernel driver for Windows operating systems
	error_708	function for returning error messages
	EXC4000	For ARINC 708 modules on PCI carrier boards - functions for extracting information associated with the carrier board.
	EXCv4000	For ARINC 708 modules on VME/XVI carrier boards - functions for extracting information associated with the carrier board.
	init_708	Initialization and Release module functions
Source Header files	config_708	Header file for configuration functions
	comm_708	Header file for communication functions
	deviceio_708	Header file for interaction with kernel driver
	error_devio	Header file containing error codes for the Excalibur kernel drivers
	error_708	Header file containing error message codes
	EXC4000	For an ARINC 708 module on PCI carrier boards - Header file containing prototypes for functions associated with the carrier board
	EXCv4000	For an ARINC 708 module on VME/VXI carrier boards - Header file containing prototypes for functions associated with the carrier board.
	Excsysio	Header file which defines control codes in kernel drivers and defines strings for module names for use in Init_Module_708 calls to kernel drivers
	Flags_708	Header file containing flags for <i>ARINC 708 Software Tools</i>
	Instance_708	Header file for global module structure
	proto_708	Header file, prototypes of all functions. This will include all the header files needed for applications
	708Incl	Header file, include for recompiling the 708 dll code, not for applications
	Reg_708	Header file containing data structures
Demo Programs	demo_708_int	Interrupt demo
	demo_708	Demo illustrating functions of <i>ARINC 708 Software Tools</i>
	demo_708_loop back	Demo illustrating loopback functions

	File Name	Description
DLL and LIB files	The DLL and LIB files have the same filename except for the file extension. The filename is: exc708Ms	
	A board level DLL accompanies the module for each of the boards and cards. Depending on the board, the names of the files are:	
	Carrier Board	DLL Name
	VME and VXI	EXCV4000MS.DLL
	All Other Boards/ Cards	EXC4000MS.DLL

Appendix D Code Index

ARINC 708 Software Tools is a set of C language functions designed to aid users of the ARINC 708 module to write test programs. Below is an alphabetical listing of all the functions and the name of the *Software Tools* file which contains its programming code.

Driver Functions	Code File Name (*.c)
ClearStatus_708	comm_708
Get_Error_String_708	error_708
Get_Interrupt_Count_708	deviceio_708
GetHWRev_708	init_708
GetModuleTimetag_708	init_708
GetPixel_708	comm_708
GetStatus_708	comm_708
Init_Module_708	init_708
InitializeInterrupt_708	deviceio_708
ModuleTimetagReset_708	init_708
NumberWordsInBuffer_708	comm_708
ReadWord_708	comm_708
Release_Module_708	init_708
SetControlData_708	comm_708
SetEventFrequency_708	config_708
SetInterrupt_708	config_708
SetLoopback_708	init_708
SetPixel_708	comm_708
SetTransmitInterval_708	config_708
SetTrigger_708	config_708
SetupReceiveChannel_708	config_708
SetupTransmitChannel_708	config_708
StartReceive_708	comm_708
StartTransmit_708	comm_708
Stop_708	comm_708
Wait_for_Interrupt_708	deviceio_708
Wait_for Multiple Interrupts_708	deviceio_708
WriteWord_708	comm_708

Appendix E Error Messages

All functions for *ARINC 708 Software Tools* are written as C functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_708` function. Below is a list of all *Software Tools* error messages, the negative value of each, and an explanation of the error

Error	Value	Explanation
einval	-2	Illegal value used as an input
sim_no_mem	-5	No memory for simulation
etimeoutreset	-26	Timed out waiting for reset
ewrngmodule	-27	Module specified on carrier board is not an ARINC 708 module
enomodule	-28	No module present at the specified location
ebadhandle	-33	Invalid handle specified; should be value returned by <code>Init_Module_708</code>
eboardtoomany	-36	Too many modules initialized
noirqset	-53	No interrupt allocated.
einvalchan	-200	Tried to set channel to illegal value
ebadchanhandle	-203	Invalid handle specified, should be value returned by channel setup routine
echantype	-204	Function invalid for this channel type
enoxmtword	-205	No room to transmit ARINC 708 word
enorcvword	-206	No ARINC 708 word received
ebadformat	-207	No proper ARINC 708 word found in receive buffer
erunning	-208	Channel already running
eoneshot	-209	Cannot write to buffer when channel running in ONESHOT mode
eretransmit	-210	Cannot write to buffer when channel running in RETRANSMIT mode

For PCI boards only

Error Code	Value	Explanation
eopenkernel	-1001	Cannot open kernel device; check Excalibur Configuration Utility settings
ekernelcantmap	-1002	Kernel driver cannot map memory
ereleventhandle	-1003	Error in kernel Release_Event_Handle
egetintcount	-1004	Error in kernel Get_Interrupt_Count
egetchintcount	-1005	Error in kernel Get_Channel_Interrupt_Count
egetintchannels	-1006	Error in kernel Get_Interrupt_Channels
ewriteiobyte	-1007	Error in kernel writeiobyte
ereadiobyte	-1008	Error in kernel readiobyte
egeteventhand1	-1009	Error in kernel Get_Event_Handle, first part
egeteventhand2	-1010	Error in kernel Get_Event_Handle, second part
eopenscmant	-1011	Error in openscmanager in startkerneldriver
eopenservicet	-1012	Error in openservice in startkerneldriver
estartservice	-1013	Error in startservice in startkerneldriver
eopenscmanp	-1014	Error in openscmanager in stopkerneldriver
eopenservicep	-1015	Error in openservice in stopkerneldriver
econtrolservice	-1016	Error in controlservice in stopkerneldriver
eunmapmem	-1017	Error in kernel unmapmemory
egetirq	-1018	Error in Get_IRQ_Number
eallocresources	-1019	Error allocating resources. See readme.pdf for details on resource allocation problems.
egetramsize	-1020	Error in kernel getramsize
ekernelwriteattrib	-1021	Error in kernel write attribute
ekernelreadattrib	-1022	Kernel read attribute error
ekernelfrontdesk	-1023	Kernel frontdesk error
ekerneloscheck	-1024	Kernel Oscheck error
ekernelfrontdeskload	-1025	Kernel frontdeskload error
ekerneliswin2000compatible	-1026	Kernel iswin2000compatible error
ekernelbankramsize	-1027	Kernel banksize error
ekernelgetcardtype	-1028	Kernel getcardtype error
emodnum	-1029	Invalid module number specified

Error Code	Value	Explanation
regnotset	-1030	Board not configured. Reboot after ExcConfig is run and board is in slot
ekernelbankphysaddr	-1031	Error in GetBankPhysAddress
ekernelclosedevice	-1032	Error in CloseKernelDrive
ekerneldevicenotopen	-1034	Kernel error: device is not opened
ekernelinitmodule	-1035	Kernel initialization error
ekernelbadparam	-1036	Kernel error: bad input parameter
ekernelbadpointer	-1037	Kernel error: invalid pointer to output buffer
ekerneltimeout	-1038	Wait for Interrupt function returned with timeout
ekernelnotwin2000	-1039	Operating System is not Windows 2000
erquestnotification	-1040	Request_Interrupt_Notification error
ekernelnot4000Card	-1041	Designated Board is not an EXC-4000/8000 family carrier board
enotimersirig	-1042	Timers and IrigB not supported on this version of the carrier board
eclocksource	-1059	If an invalid clock source was specified
eparmglobalreset	-1062	Illegal parameter used for <code>globalreset_flag</code> in StartTimer
etimernotrunning	-1063	Timer not running when ResetWatchdogTimer was called; did nothing
etimerrunning	-1064	Timer already running when StartTimer was called; did nothing
eparmreload	-1065	Illegal parameter used for <code>reload_flag</code> in StartTimer
eparminterrupt	-1066	Illegal parameter used for <code>interrupt_flag</code> in StartTimer
ebaddevhandle	-1067	Invalid handle specified. Use value returned by Init_Timers
edevtoomany	-1068	Init_Timers called for too many boards
einvalidOS	-1069	If an invalid operating system is used

For VME/VXI boards only

Error Code	Value	Explanation
eviclosedev	-1050	Error in ViClose device
evicloserm	-1051	Error in ViClose Default RM
eopendefaultrm	-1052	Error in ViOpenDefault RM
eviopen	-1053	Error in ViOpen
evimapaddress	-1054	Error in viMapAddress
evicommand	-1055	Error in VISA command
einstallhandler	-1056	Error in VISA viInstallHandler
eenableevent	-1057	Error in VISA viEnableEvent
euninstallhandler	-1058	Error in VISA viUninstallHandler
eclocksource	-1059	If an invalid clock source was specified
edevnum	-1060	If a device number greater than 255 was used
einstr	-1061	If a device was not successfully initialized by Init_Module_708

Functions Index

C

ClearStatus_708, 4-1

G

Get_Error_String_708, 2-6
Get_Interrupt_Count_708, 5-2
GetControlData_708, 4-7
GetData_708, 4-6
GetHWRev_708, 2-4
GetModuleTimetag_708, 2-5
GetPixel_708, 4-6
GetStatus_708, 4-2

I

Init_Module_708, 2-2
InitializeInterrupt_708, 5-3

M

ModuleTimetagReset_708, 2-5

N

NumberWordsInBuffer_708, 4-2

R

ReadWord_708, 4-3
Release_Module_708, 2-3

S

SetControlData_708, 4-7
SetData_708, 4-6
SetEventFrequency_708, 3-4
SetInterrupt_708, 3-3
SetLoopback_708, 2-4
SetPixel_708, 4-7
SetTransmitInterval_708, 3-3
SetTrigger_708, 3-4
SetupReceiveChannel_708, 3-2
SetupTransmitChannel_708, 3-2
StartReceive_708, 4-3
StartTransmit_708, 4-4
Stop_708, 4-4

W

Wait_For_Interrupt_708, 5-4
Wait_for_Multiple_Interrupts_708, 5-5
WriteWord_708, 4-5

The information contained in this document is believed to be accurate. However, no responsibility is assumed by Excalibur Systems, Inc. for its use and no license or rights are granted by implication or otherwise in connection therewith. Specifications are subject to change without notice.

December 2020, Rev A-3