

M4K708
Software Tools
Programmer's Reference



Table of Contents

1 Introduction	
Getting Started	1-2
Installation.....	1-2
Multiple Board Support	1-2
The Excalibur Systems Website	1-3
The M4K708 Module	1-3
Overview of the Weather Radar Display Databus	1-3
M4K708 Module.....	1-4
M4K708 Software Tools Functions	1-5
M4K708 Software Tools for the EXC-4000 Family of Carrier Boards.....	1-5
Get_4000Module_Type for PCI boards	1-6
Get_4000Module_Type for VME/VXI boards	1-7
Select_Time_Tag_Source_4000	1-8
Compiler Options	1-9
Conventions Used in the Programmer's Reference	1-9
2 M4K708 Initialization Functions	
Init_Module_708	2-2
Release_Module_708.....	2-3
GetHWRev_708.....	2-4
SetLoopback_708.....	2-4
GetModuleTimetag_708	2-5
ModuleTimetagReset_708.....	2-5
Get_Error_String_708.....	2-6
3 M4K708 Configuration Functions	
Event Generation: Status, Interrupts and Output Triggers	3-1
Channel Status Bit.....	3-1
Interrupt/Trigger	3-1
SetupTransmitChannel_708	3-2
SetupReceiveChannel_708	3-2
SetInterrupt_708	3-3
SetTransmitInterval_708.....	3-3
SetTrigger_708	3-4
SetEventFrequency_708	3-4
4 M4K708 Communication Functions	
ClearStatus_708	4-1
GetStatus_708	4-2
NumberWordsInBuffer_708	4-2
ReadWord_708.....	4-3
StartReceive_708	4-4
StartTransmit_708	4-4
Stop_708	4-5
WriteWord_708	4-5
ARINC 708 WORD Utility Functions	4-6
GetData_708	4-6
SetData_708.....	4-6

GetPixel_708	4-6
SetPixel_708.....	4-7
GetControlData_708	4-7
SetControlData_708	4-7

5 Using Interrupt Functions

Get_Interrupt_Count_708	5-2
InitializeInterrupt_708	5-3
Wait_for_Interrupt_708	5-4
Wait_for Multiple_Interrupts_708	5-5

A: ARINC 708 Specifications	A-1
--	------------

B: EXC-4000PCI Boards: Installation Instructions.....	B-1
--	------------

C: EXC-4000VME Boards: Installation Instructions for PCI-MXI-2 Systems.....	C-1
--	------------

D: Multiple Board Support for EXC-4000 Carrier Boards	D-1
--	------------

E: Flags for Use with <i>M4K708 Software Tools</i>	E-1
---	------------

F: <i>M4K708 Software Tools</i> Library	F-1
--	------------

G: Code Index.....	G-1
---------------------------	------------

H: Error Messages	H-1
--------------------------------	------------

1 Introduction

Chapter 1 provides an overview for *M4K708 Software Tools* and the avionics communication hardware for the *M4K708 Weather Radar Display Databus* module on the EXC-4000 family of carrier boards.

Getting Started	1-2
Installation	1-2
4000PCI Carrier Boards	1-2
4000VME/VXI Carrier Boards	1-2
Multiple Board Support.....	1-2
4000PCI Carrier Boards	1-2
4000VME/VXI Carrier Boards	1-2
The Excalibur Systems Website	1-3
The M4K708 Module.....	1-3
Overview of the Weather Radar Display Databus.....	1-3
M4K708 Module	1-4
Receive Mode	1-4
Transmit Mode.....	1-4
M4K708 Software Tools Functions.....	1-5
<i>M4K708 Software Tools</i> for the EXC-4000 Family of Carrier Boards	1-5
Get_4000Module_Type for PCI boards	1-6
Get_4000Module_Type for VME/VXI boards.....	1-7
Select_Time_Tag_Source_4000.....	1-8
Compiler Options	1-9
Conventions Used in the Programmer's Reference	1-9

Getting Started

Before starting to write applications:

1. On the *Excalibur Installation CD*, included in the package you received with the hardware:
 - Locate the appropriate *M4K708 Software Tools* for your hardware
 - Download a copy of *M4K708 Software Tools: Programmer's Reference*
 - Be sure to download a copy of your hardware's *User's Manual*.
2. Install the hardware. For hardware installation instructions, refer to the *User's Manual*.
3. Fill out the registration card and return it to your Excalibur representative.

Note: If anything is missing or damaged, contact your Excalibur representative.

Installation

4000PCI Carrier Boards

For PCI and cPCI carrier boards, see **Appendix B: EXC-4000PCI Boards: Installation Instructions** for hardware and software installation instructions.

4000VME/VXI Carrier Boards

For VME or VXI carrier boards, see **Appendix C: EXC-4000VME Boards: Installation Instructions for PCI-MXI-2 Systems** for hardware and software installation instructions.

Multiple Board Support

4000PCI Carrier Boards

The Excalibur Configuration Utility program (**ExcConfig.exe**) is a configuration setup program for PCI and cPCI boards. Use the utility program to specify which board in a machine is being used. *M4K708 Software Tools* supports the use of up to four PCI or cPCI boards simultaneously. Only if more than one board is used, is it necessary to run the utility program. If one board is used, the define value EXC_4000PCI can be used instead of the device number.

The configuration program allows the user to set or change settings on the board itself. Excalibur boards will work only after device values are properly entered and saved in the **ExcConfig.exe** utility. Instructions for entering values in the utility program are in:

- **Appendix D: Multiple Board Support for EXC-4000 Carrier Boards** and
- In the **readme.pdf** file, on the *Excalibur Installation CD*, you received with your Excalibur board.

4000VME/VXI Carrier Boards

To configure multiple VME and VXI boards, see the section **EXC-4000VME and EXC-4000VXI Boards** on page D-2 in **Appendix D: Multiple Board Support for EXC-4000 Carrier Boards**.

The Excalibur Systems Website

The software provided with Excalibur boards and modules is for Windows operating systems. The latest versions of the software and the *M4K708 Software Tools: Programmer's Reference* can be downloaded from our website. Check our website periodically for the latest updates: www.mil-1553.com.

In addition, information about our full range of products can be found at this site.

For further assistance, contact your Excalibur representative or write to excalibur@mil-1553.com.

The M4K708 Module

The *M4K708* is an interface module for the Excalibur EXC-4000 family of carrier boards. This module supports the ARINC 708/453 Airborne Weather Radar protocol.

Overview of the Weather Radar Display Databus

The Weather Radar protocol consists of 1600-bit ARINC 708 words, which, when interpreted and plotted together, form a picture of weather patterns in the surrounding area. The various weather conditions are indicated by the colors displayed.

The picture is formed as follows: emanating from the center of a circle, a single radius line at a time is drawn, where each radius line is the data from a single ARINC 708 word.

Each ARINC 708 word is composed of 64 bits of control information, including the scan angle - the angle at which that line is to be drawn on the circle, and 512 'bins' - each one a 3-bit value specifying the color of a pixel to be drawn along that line.

Scan angle information is stored in the 12 bits between bit 52 (the 52nd bit received) and bit 63. Angle 0 degrees is "dead ahead" (up); angle 90 degrees is "right wing" (to the right). The angle to be used for drawing this line of data is determined by the combination of the 12 bits, which are defined as follows:

Bit	Angle (in degrees)	Bit	Angle (in degrees)
63	180	57	2.8125
62	90	56	1.40625
61	45	55	0.703125
60	22.5	54	0.3415625
59	11.25	53	0.17578125
58	5.625	52	0.087890625

Table 1-1 Scan Angle

The weather conditions represented by the 3-bit pixel data are:

Pixel Value (3 bits)	Weather Condition
0	no precipitation
1	light precipitation
2	moderate precipitation
3	heavy precipitation
4	very heavy precipitation
5	reserved
6	medium turbulence
7	heavy turbulence

Table 1-2 Pixel Values

Some radar displays do not require 512 pixels, they may use only 128 or 256 pixels. Such devices have the option of repeating the data more than once which would allow for data error detection. When less than 512 pixels are used, the actual pixels can occupy the first block of the 'bin' space or, alternatively, the actual pixels may be interleaved with the unused ones.

M4K708 Module

The *M4K708* module contains two ARINC 708/453 channels, each software-selectable as transmit or receive.

Receive Mode

Each incoming ARINC 708 message is composed of 103 16-bit words comprising: two words of timetag, 100 words of ARINC 708 data, and a status word. The user sets the receive channel to receive data on the bus. When the user reads a word, the drivers will check if a complete message is available for reading and return it if it is. Each 16-bit word is checked to verify that the expected word type – time tag, data or status – was read and the entire ARINC 708 is checked for Manchester errors. Interrupts can be generated upon receipt of a specified number of ARINC 708 words, or upon error condition indicating receive data overrun.

Transmit Mode

Each outgoing ARINC 708 message is composed of ARINC 708 data words. The user can write up to 655 ARINC 708 words to a buffer. The drivers will inform the user if there is no space left on the module for more words, in which case the user should wait until the module empties the buffer by transmitting the data currently in the buffer. The user sets the transmit channel to send data on the bus, continuously, one-shot (only one ARINC 708 word at a time) or retransmit mode (the contents of the buffer are retransmitted over and over until stopped). Interrupts can be generated upon transmission of a specified number of ARINC 708 words, or upon error condition indicating that there is no data to transmit.

For more information about Receive and Transmit modes, see the *M4K708 Module User's Manual*.

M4K708 Software Tools Functions

The *M4K708 Software Tools* is a set of 'C' language functions designed to aid users of Excalibur's *M4K708* modules to write test programs. These functions provide access to all of the *M4K708 Software Tools* functions in a structured and straightforward programming environment.

M4K708 Software Tools is available for Windows 9x/*ME*, NT, 2000 and XP. The Windows functions were written and tested using Borland C++ and Microsoft Visual C++.

M4K708 Software Tools for the EXC-4000 Family of Carrier Boards

There are numerous modules available for use on the EXC-4000 carrier board. To date, Excalibur provides M4K708, M4K429/RTx, M4K1553Px, M4K1553/MCH, M4KDiscrete, M4KSerial and M4KH009 modules.

Various combinations of these modules may be present on the board at one time. One application may access any of the following configurations:

- one module
- multiple modules of the same type located on one board
- multiple modules of the same type located on separate boards
- multiple modules of different types located on one or separate boards

A general-purpose DLL accompanies the *M4K708* module for each of the EXC-4000 boards. Depending on the carrier board and compiler used, the names of the files are:

Carrier board	Borland	Microsoft
4000PCI	EXC4000.DLL	EXC4000MS.DLL
4000VME/VXI	EXCV4000.DLL	EXCV4000MS.DLL

The functions that operate at the 4000 carrier board level are contained in the **EXC4000.c** file for EXC-4000PCI carrier boards and the **EXCV4000.c** file for EXC-4000VME/VXI boards. The function, `Get_4000Module_Type` may be called for each board and module number, to check which, if any, modules are currently available at that location. (This function is also called automatically from `Init_Module_708` to ascertain that the type of module is a *M4K708* module.) These DLLs are installed automatically in the Windows/System folder when the *Software Tools* are installed for modules.

The function `Select_Time_Tag_Source_4000` sets the Time tag source for all the modules on the carrier board. The Time Tag source cannot be set for individual modules.

For other functions that operate at the carrier board level see the applicable carrier board's *Programmer's Reference*.

Get_4000Module_Type for PCI boards

Description	Get_4000Module_Type for PCI boards checks which, if any, module is currently in the specified location. Up to four <i>MAK708</i> modules can be mounted on a 4000PCI carrier board.	
Syntax	Get_4000Module_Type (WORD device_num, WORD module_num, WORD *modtype)	
Input Parameters	device_num	The define value EXC_4000PCI can be used instead of a device number. If more than one board is used, run ExcConfig to set the device number
	module_num	A module position number: A value 0 – 3
Output Parameters	modtype	EXC4000_MODTYPE_708 If there is a 708 module EXC4000_MODTYPE_H009 If there is a H009 module EXC4000_MODTYPE_PX If there is a Px module EXC4000_MODTYPE_MCH If there is an MCH module EXC4000_MODTYPE_SERIAL If there is a Serial module EXC4000_MODTYPE_RTX If there is an RTx module EXC4000_MODTYPE_DIO If there is a Discrete module EXC4000_MODTYPE_NONE If there is no module present
Return Values	emodnum	If an invalid module number was specified
	ekernelnot4000card	If the designated board is not a 4000PCI board
	0	If successful

Get_4000Module_Type for VME/VXI boards

Description	Get_4000Module_Type for VME/VXI boards checks which, if any, module is in the currently specified location. Up to eight <i>M4K708</i> modules can be mounted on a VME/VXI carrier board.	
Syntax	Get_4000Module_Type (WORD device_num, WORD module_num, WORD *modtype)	
Input Parameters	device_num	A device number (0–255) as set with the DIP switches. See Appendix C: EXC-4000VME Boards: Installation Instructions for PCI-MXI-2 Systems.
	module_num	A module position number: A value 0 – 7
Output Parameters	modtype	EXC4000_MODTYPE_708 If there is a 708 module EXC4000_MODTYPE_H009 If there is a H009 module EXC4000_MODTYPE_PX If there is a Px module EXC4000_MODTYPE_MCH If there is an MCH module EXC4000_MODTYPE_SERIAL If there is a Serial module EXC4000_MODTYPE_RTX If there is an RTx module EXC4000_MODTYPE_DIO If there is a Discrete module EXC4000_MODTYPE_NONE If there is no module present
Return Values	emodnum	If an invalid module number was specified
	eopendefaultrm	If error in viOpenDefaultRM
	eviopen	If error in viOpen
	evimapaddress	If error in viMapAddress
	0	If successful

Select_Time_Tag_Source_4000

Description	Select_Time_Tag_Source_4000 selects the source of the Time Tag used in all modes and for all modules on the board. It is one setting for <i>all</i> the modules used.	
Syntax	Select_Time_Tag_Source_4000 (WORD device_num, WORD source)	
Input Parameters	device_num	<p>EXC-4000PCI/cPCI The define value EXC-4000PCI can be used instead of a device number. If more than one board is used, run ExcConfig to set the device number</p> <p>EXC-4000VME/VXI A device number (0–255) as set with the DIP switches. See Appendix C: EXC-4000VME Boards: Installation Instructions for PCI-MXI-2 Systems.</p>
	source	<p>INTERNAL_CLOCK Uses the board's 4 µsec. timer</p> <p>EXTERNAL_CLOCK See “External Signals Connector” in the Mechanical and Electrical Specifications chapter in the applicable hardware <i>User's Manual</i></p>
Output Parameters	none	
Return Values	einval	If an invalid parameter was used as an input
	eclocksource	If an invalid clock source was specified
	0	If successful

Compiler Options

Programmers *must* use one of the following calling options, depending on the compiler used:

- The Borland DLL is compiled using `_stdcall` options
- The Microsoft DLL is compiled using `_cdecl` options

The driver functions in *M4K708 Software Tools* are supplied both in source form and linked as a DLL. When writing application programs, keep in mind that the module is a physical resource, and therefore you cannot run multiple copies of the program simultaneously.

Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for inputs where applicable. All structures and flags used by *M4K708 Software Tools* functions are defined in **Appendix E Flags for Use with M4K708 Software Tools**.

Functions are written as 'C' functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_708` function. (See **Appendix H: Error Messages**).

In Windows all user-defined programs must include the file `proto_708.h`. This file includes all the necessary header files and **DLL** function prototypes to operate *M4K708 Software Tools*.

Conventions Used in the Programmer's Reference

To help differentiate between different kinds of information, the following character styles are used in the *Programmer's Reference*:

Functions look like this.

Variables look like this

Parameter look like this.

File names look like this.

FLAGS look like this

Note: WORD = unsigned short int

2 M4K708 Initialization Functions

Chapter 2 contains descriptions of the initialization functions necessary to write test programs for the *M4K708* module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The flags included in each function are defined in **Appendix E: Flags for Use with M4K708 Software Tools**.

The functions described in this chapter are:

- Init_Module_708
- Release_Module_708
- GetHWRev_708
- SetLoopback_708
- GetModuleTimetag_708
- ModuleTimetagReset_708
- Get_Error_String_708

Init_Module_708

Description	<p>Init_Module_708 is the first function the user must call for each <i>M4K708</i> module on each device that is accessed in the application program.</p> <p>Before exiting a program, call Release_Module_708 for each module initialized with Init_Module_708.</p> <p>On EXC-4000PCI or EXC-4000cPCI carrier boards, Init_Module_708 enables the user to access up to four modules on a single board or any combination of up to 16 modules on four separate boards.</p> <p>On EXC-4000VME or EXC-4000VXI carrier boards, Init_Module_708 enables the user to access up to eight modules on a single board or any combination of up to 32 modules on four separate boards.</p> <p>The function may be called with the SIMULATE argument. If the SIMULATE argument is used, a portion of the memory equal to the size of the board's dual-port RAM is set aside. This area is then initialized with an id and version number for use in testing programs when no module is available.</p> <p>Multiple modules may be simulated. It is possible to have real or SIMULATED modules in one application.</p> <p>On EXC-4000PCI or EXC-4000cPCI carrier boards up to 17 real or SIMULATED modules may be initialized.</p> <p>On EXC-4000VME or EXC-4000VXI carrier boards up to 33 or SIMULATED modules may be initialized.</p> <p>More than one module may be SIMULATED simultaneously.</p>								
Syntax	Init_Module_708 (int device_num, int module_num)								
Input parameters	<table border="0"> <tr> <td style="padding-right: 20px;">device_num</td> <td>The device number is the index of the entry value set in ExcConfig: 0 - 4</td> </tr> <tr> <td style="text-align: center; padding: 5px 0;">or</td> <td></td> </tr> <tr> <td style="padding-right: 20px;">SIMULATE</td> <td>If no module is present</td> </tr> <tr> <td style="padding-right: 20px;">module_num</td> <td>The module number of the <i>M4K708</i> module on the board specified by device_num: 0 - 4</td> </tr> </table>	device_num	The device number is the index of the entry value set in ExcConfig: 0 - 4	or		SIMULATE	If no module is present	module_num	The module number of the <i>M4K708</i> module on the board specified by device_num: 0 - 4
device_num	The device number is the index of the entry value set in ExcConfig: 0 - 4								
or									
SIMULATE	If no module is present								
module_num	The module number of the <i>M4K708</i> module on the board specified by device_num: 0 - 4								
Note:	If only one board is used, the define value EXC_4000PCI (default device number = 25) can be used instead of a device number. If more than one board is used the programmer must run the ExcConfig utility to set the device number.								
Output parameters	none								
Return Values	<table border="0"> <tr> <td style="padding-right: 20px;">eopenkernel</td> <td>If there was an error opening a device</td> </tr> <tr> <td style="padding-right: 20px;">emodnum</td> <td>Invalid module number specified</td> </tr> </table>	eopenkernel	If there was an error opening a device	emodnum	Invalid module number specified				
eopenkernel	If there was an error opening a device								
emodnum	Invalid module number specified								

Init_Module_708 (cont.)

enomodule	If no EXC-4000 module present at specified location
ewrngmodule	If module specified on EXC-4000PCI board is not <i>M4K708</i> module
etimeoutreset	If timed out waiting for reset
eboardtoomany	If too many boards initialized
sim_no_mem	If no memory for simulation
enoid	If could not find a module at given device address
devhandle	If successful, the handle to the specified module on the board. EXC-4000CPI and EXC-4000cPCI A valid handle is a positive number ranging from 0–16. EXC-4000VME and EXC-4000VXI A valid handle is a positive number ranging from 0–32.

Release_Module_708

Description	Release_Module_708 releases any grabbed resources on a specific module. Call the function for each module initialized with Init_Module_708, before exiting a program. To continue accessing the module, call Init_Module_708.
Syntax	Release_Module_708 (int devhandle)
Input Parameters	devhandle The handle designated by Init_Module_708.
Output Parameters	none
Return Values	ebadhandle If an invalid devhandle was specified; must be value returned by Init_Module_708 0 If successful

GetHWRev_708

Description	GetHWRev_708 returns the hardware revision number.	
Syntax	GetHWRev_708 (int devhandle, int *hwrev)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
Output Parameters	hwrev	Returns the current FPGA revision level of the module
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	0	If successful

SetLoopback_708

Description	SetLoopback_708 sets up the module to loopback mode, where one channel on the module transmits to the other, internally, without a cable.	
Syntax	SetLoopback_708 (int devhandle, int flag)	
Input parameters	devhandle	The handle designated by Init_Module_708
	flag	ENABLE To set up internal loopback mode DISABLE To disable loopback mode
Output parameters	none	
Return values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	einval	If an illegal value is used as an input
	0	If successful

GetModuleTimetag_708

Description	GetModuleTimetag_708 gets the current value of the running Time tag on the module.	
Syntax	GetModuleTimetag_708 (int_devhandle, unsigned int *timetag)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	timetag	32-bit Time tag
Return Values	ebadhandle	If invalid handle specified; must be value returned by Init_Module_708.
	0	If successful

ModuleTimetagReset_708

Description	ModuleTimetagReset_708 sets the value of the running Time tag on the module to 0.	
Syntax	ModuleTimetagReset_708 (int_devhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	none	
Return Values	ebadhandle	If invalid handle specified; must be value returned by Init_Module_708.
	0	If successful

Get_Error_String_708

Description	Get_Error_String_708 accepts the error of return values from other <i>M4K708 Software Tools</i> functions. This function returns the string containing a corresponding error message.	
Syntax	Get_Error_String_708 (int errcode, int errlen, char* errstring)	
Example:	<pre>#define ERRORLEN 255 char ErrorStr[ERRORLEN]; Get_Error_String_708 (errorcode, ERRORLEN, &ErrorStr); printf("error is: %s", ErrorStr);</pre>	
Input Parameters	errcode	The error code returned from a <i>Software Tools</i> call.
	errlen	Maximum length of string to be returned - the message string that contains the corresponding error message
Output Parameters	errorstring	An array of 'errlen' characters, the message string that contains the corresponding error message. In case of bad input, this function returns a string denoting that.
Return Values	0	Always

3 M4K708 Configuration Functions

Chapter 3 contains descriptions of the configuration functions necessary to write test programs for the *M4K708* module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The flags included in each function are defined in **Appendix E: Flags for Use with M4K708 Software Tools**.

The functions described in this chapter are:

SetupTransmitChannel_708
SetupReceiveChannel_708
SetInterrupt_708
SetTransmitInterval_708
SetTrigger_708
SetEventFrequency_708

Event Generation: Status, Interrupts and Output Triggers

Three events can occur:

- A bit is set in the Channel Status register - the status bits are read by `GetStatus_708` and are cleared with `ClearStatus_708`. (See `GetStatus_708` on page 4-2 and `ClearStatus_708` on page 4-1)
- An interrupt is generated
- An output trigger is generated

Channel Status Bit

The TXRX status bit is set for a receive channel when a specified number of ARINC 708 words is received by the channel. (See `SetEventFrequency_708` on page 3-4)

The TXRX status bit is set for a transmit channel when a specified number of ARINC 708 words is received by the channel (See `SetEventFrequency_708` on page 3-4)

The error status bit is set for a receive channel when receiving and the buffer is full – overrun condition.

An error status bit is set for a transmit channel when transmitting in CONTINUOUS or RETRANSMIT mode, and the buffer is empty.

Interrupt/Trigger

An interrupt/trigger is generated when the conditions above are fulfilled, and the interrupt/trigger has been enabled for that condition, for the channel. (See `SetInterrupt_708` on page 3-3 and `SetTrigger_708` on page 3-4).

SetupTransmitChannel_708

Description	SetupTransmitChannel_708 resets the channel and sets it to transmit.	
Syntax	SetupTransmitChannel_708 (int devhandle, int channel, int *chanhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
	channel	The channel number [0 or 1]
Output Parameters	chanhandle	The handle to the specified channel on the module. This handle is the first parameter in all channel specific functions.
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	etimeoutreset	If timed out waiting for reset.
	EINVALCHAN	If tried to set a channel to an illegal value
	0	If successful

SetupReceiveChannel_708

Description	SetupReceiveChannel_708 resets the channel and sets it to receive.	
Syntax	SetupReceiveChannel_708 (int devhandle, int channel, int *chanhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708.
	channel	The channel number [0 or 1]
Output Parameters	chanhandle	The handle to the specified channel on the module. This handle is the first parameter in all channel specific functions.
Return Values	ebadhandle	If an invalid devhandle was specified; must be value returned by Init_Module_708
	etimeoutreset	If timed out waiting for reset.
	EINVALCHAN	If tried to set a channel to an illegal value
	0	If successful

SetInterrupt_708

Description	SetInterrupt_708 sets the condition or conditions under which the module is to generate interrupts for the <i>M4K708</i> module.
Syntax	SetInterrupt_708 (int chanhandle, WORD interrupt_type)
Input Parameters	<p>chanhandle The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708</p> <p>interrupt_type One or both ORed together:</p> <p style="padding-left: 2em;">TXRX_INTERRUPT Interrupt after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708.</p> <p style="padding-left: 2em;">ERROR_INTERRUPT Interrupt when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition</p> <p style="padding-left: 2em;">or</p> <p style="padding-left: 2em;">NO_INTERRUPT To disable interrupt generation</p>
Output Parameters	none
Return Values	<p>ebadchanhandle If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.</p> <p>noirqset If no interrupt allocated</p> <p>EINVAL If an illegal value is used as an input</p> <p>0 If successful</p>

SetTransmitInterval_708

Description	SetTransmitInterval_708 sets the interval between the beginning of one ARINC 708 word and the next ARINC 708 word in microseconds.
Syntax	SetTransmitInterval_708 (int chanhandle, WORD interval_micro)
Input Parameters	<p>chanhandle The handle returned by SetupTransmitChannel_708</p> <p>interval_ 1600 – 65535: Interval value in microseconds</p> <p>micro Default value is 5500</p>
Output Parameters	none
Return Values	<p>ebadchanhandle If an invalid channel value is specified. Must be the handle returned by SetupTransmitChannel_708.</p> <p>EINVAL If an illegal value is used as an input</p> <p>0 If successful</p>

SetTrigger_708

Description	SetTrigger_708 sets the condition or conditions under which the module is to generate an output trigger.
Syntax	SetTrigger_708 (int chanhandle, WORD trigger_type)
Input Parameters	<p>chanhandle The handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708</p> <p>trigger_type One or both ORed together: TXRX_TRIGGER Trigger after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708. ERROR_TRIGGER Trigger when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition <i>or</i> NO_TRIGGER To disable output triggering</p>
Output Parameters	none
Return Values	<p>ebadchanhandle If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.</p> <p>EINVAL If an illegal value is used as an input</p> <p>0 If successful</p>

SetEventFrequency_708

Description	SetEventFrequency_708 sets the desired number of ARINC 708 words to be transmitted/received either before setting the channel status bit, or generating an interrupt, or an output trigger.
Syntax	SetEventFrequency_708 (int chanhandle, WORD frequency)
Input Parameters	<p>chanhandle The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708</p> <p>frequency The frequency at which to generate a status bit or interrupt: Default value is 1 Module rev B: Maximum values Transmit 655 Receive 636 Module rev A: values 1 – 80</p>
Output Parameters	none
Return Values	<p>ebadchanhandle If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.</p> <p>EINVAL If an illegal value is used as an input</p> <p>0 If successful</p>

4 M4K708 Communication Functions

Chapter 4 contains descriptions of the receive and transmit communication functions necessary to write test programs for the *M4K708* module. Each function is presented with its formal definition, including data types of all input and output variables. A brief description of the purpose of the function is provided along with the legal values for the inputs, where applicable.

The **communication** functions are:

ClearStatus_708	StartReceive_708
GetStatus_708	StartTransmit_708
NumberWordsInBuffer_708	Stop_708
ReadWord_708	WriteWord_708

The **ARINC 708 utility** functions are:

GetData_708	SetControlData_708
SetData_708	GetPixel_708
GetControlData_708	SetPixel_708

See **Appendix E: Flags for Use with M4K708 Software Tools** for typedef of control data structure.

ClearStatus_708

Description	Call ClearStatus_708 to clear selected bits of the channel status/ interrupt status for the specified channel.	
Syntax	ClearStatus_708 (int chanhandle, WORD clearflag)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708.
	clearflag	One <i>or</i> both ORed together: TXRX_STATUS Clears the bits indicating ARINC 708 words transmitted/received ERROR_STATUS Clears bits indicating error condition <i>or</i> ALL_STATUS Clear all status bits
Output Parameters	none	
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupTransmitChannel_708 or SetupReceiveChannel_708.
	EINVAL	If an illegal value is used as an input
	0	If successful

GetStatus_708

Description	Call GetStatus_708 to read the channel status for the specified channel. This value can be used to ascertain for which channel an interrupt or trigger was generated, and the type of event – TXRX or ERROR.	
Syntax	GetStatus_708 (int chanhandle, int statusflag)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
Output Parameters	statusflag	One <i>or</i> both ORed together TXRX_STATUS The number of ARINC 708 words set in SetEventFrequency_708 was transmitted/received ERROR_STATUS Error occurred on channel <i>or</i> NO_STATUS No channel status set
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708.
	0	If successful

NumberWordsInBuffer_708

Description	NumberWordsInBuffer_708 returns the number of words currently in the buffer for the specified channel.	
Syntax	NumberWordsInBuffer_708 (int chanhandle, int *numwords)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708.
Output Parameters	numwords	Number of words currently in the buffer returned for the specific channel. Values: 0 – 65536
Return Values	ebadhandle	If an invalid handle was specified; should be value returned by Init_Module_708
	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708.
	0	If successful

ReadWord_708

Description	ReadWord_708 reads one ARINC 708 word from the buffer for the specified receive channel.	
Syntax	ReadWord_708 (int chanhandle, WORD *wordarray, DWORD *timetag, WORD *wordstatus)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708.
Output Parameters	wordarray	Pointer to 100 WORDs containing one ARINC 708 word
	timetag	A 32-bit Timetag
	wordstatus	INVALID_708WORD Manchester error VALID_708WORD Valid 708 word
Return Values	ebadchanhandle	If an invalid channel value is specified. Must be the handle returned by SetupReceiveChannel_708.
	echantype	If channel type is not receive
	ebadformat	If no proper ARINC 708 word found in receive buffer
	enorcword	If no ARINC 708 word was received
	0	If successful

StartReceive_708

Description	Call StartReceive_708 to start receiving data in the buffer for the specified channel.	
Syntax	StartReceive_708 (int chanhandle)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupReceiveChannel_708 is used.
	echantype	If channel type is not receive
	0	If successful

StartTransmit_708

Description	Call StartTransmit_708 to start transmitting data in the buffer for the specified transmit channel.	
Syntax	StartTransmit_708 (int chanhandle, int duration)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708
	duration	DUR_ONESHOT To send out one ARINC 708 word DUR_CONTINUOUS To continuously transmit until transmit buffer is empty - buffer can be written to continuously DUR_RETRANSMIT To transmit contents of a buffer again and again until stopped - data <i>cannot</i> be written to the buffer
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupTransmitChannel_708 is used.
	echantype	If channel type is not transmit
	EINVAL	If an invalid value was used as an input
	ERUNNING	If channel already running
	0	If successful

Stop_708

Description	Call Stop_708 to stop transmitting/receiving data in the buffer for the specified channel.	
Syntax	Stop_708 (int chanhandle)	
Input Parameters	chanhandle	The handle returned by SetupReceiveChannel_708 or SetupTransmitChannel_708
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupReceiveChannel_708 or SetupTransmitChannel_708 is used.
	0	If successful

WriteWord_708

Description	WriteWord_708 writes one ARINC 708 word to the buffer for the specified channel.	
Syntax	WriteWord_708 (int chanhandle, WORD *wordarray)	
Input Parameters	chanhandle	The handle returned by SetupTransmitChannel_708
	wordarray	Pointer to 100 WORDs containing one ARINC 708 word
Output Parameters	none	
Return Values	ebadchanhandle	If handle other than the one returned by SetupTransmitChannel_708 is used.
	echantype	If function invalid for this channel type
	eoneshot	Cannot write to buffer when channel running in ONESHOT mode
	eretransmit	Cannot write to buffer when channel running in RETRANSMIT mode
	enoxmtword	If no room to transmit ARINC 708 word
	0	If successful

ARINC 708 WORD Utility Functions

See **Appendix E: Flags for Use with M4K708 Software Tools** for typedef of control data structure.

GetData_708

Description	GetData_708 reads control data and all pixel information from ARINC 708 word into structures
Syntax	GetData_708 (WORD *wordarray, t_controlData *controlData, WORD *pixelarray)
Input Parameters	wordarray Array containing one ARINC 708 word
Output Parameters	controlData Structure containing control data pixelarray Array of 512 WORDs, one for each pixel's data
Return Values	0 Always

SetData_708

Description	SetData_708 writes control data and all pixel information from structures into an ARINC 708 word.
Syntax	SetData_708 (t_controlData *controlData, WORD *pixelarray, WORD *wordarray)
Input Parameters	controlData Structure containing control data pixelarray Array of 512 WORDs, one for each pixel's data
Output Parameters	wordarray Array containing one ARINC 708 word
Return Values	0 Always

GetPixel_708

Description	GetPixel_708 reads a specific pixel from the data portion of the ARINC 708 word.
Syntax	GetPixel_708 (WORD *wordarray, int pixnum, WORD *pixel)
Input Parameters	wordarray Array of 100 WORDs containing one ARINC 708 word pixnum Pixel number: a value 1 – 512
Output Parameters	pixel One WORD. Pixel data is in the lowest 3 bits
Return Values	einval If an illegal value is used as an input 0 If successful

SetPixel_708

Description	SetPixel_708 writes a specific pixel to the data portion of the ARINC 708 word.	
Syntax	SetPixel_708 (WORD *wordarray, int pixnum, WORD *pixel)	
Input Parameters	wordarray	Array of 100 WORDs containing one ARINC 708 word
	pixnum	Pixel number: a value 1 – 512
	pixel	One WORD. Pixel data is in the lowest 3 bits
Output Parameters	wordarray	The updated array of 100 WORDs containing one ARINC 708 word
Return Values	EINVAL	If an invalid value was used as an input
	0	If successful

GetControlData_708

Description	Call GetControlData_708 to read the control data portion from the ARINC 708 word array into a structure.	
Syntax	GetControlData_708 (WORD *wordarray, t_ControlData *controlData)	
Input Parameters	wordarray	Array of 100 words containing one ARINC 708 word
Output Parameters	controlData	Structure containing control data
Return Values	0	Always

SetControlData_708

Description	Call SetControlData_708 to add control data information into a ARINC 708 word.	
Syntax	SetControlData_708 (t_controlStruct controlStruct, WORD *wordarray)	
Input Parameters	wordarray	Array of 100 words containing one ARINC 708 word
	controlStruct	Structure containing various parts of the Control data
Output Parameters	wordarray	The updated array of 100 words containing one ARINC 708 word.
Return Values	0	Always

5 Using Interrupt Functions

When writing a Windows program that processes interrupts, a separate thread is generally created to handle the interrupt processing. This thread calls `Wait_for_Interrupt_708`, in order to wait for the next interrupt. When the function returns, the interrupt is processed as needed. This method is demonstrated in the test program `demo_708_int.c` which is included with the *M4K708 Software Tools*.

Note: There is no need to reset the physical interrupt line in the interrupt thread; this is handled internally.

In cases of very high interrupt frequency, several interrupts may occur before the interrupt thread resumes execution. The `Get_Interrupt_Count_708` function may be used to determine if multiple interrupts have occurred. Conversely, it is possible that the `Wait_for_Interrupt_708` function will indicate an interrupt that has already been processed by the thread. (This will occur in the case where a subsequent interrupt occurs in between the return of the `Wait_for_Interrupt_708` function and the call to `Get_Interrupt_Count_708`.) Once again, the `Get_Interrupt_Count_708` function may be used to determine if the interrupt has already been processed.

The following functions are described in this chapter:

- Get_Interrupt_Count_708
- InitializeInterrupt_708
- Wait_for_Interrupt_708
- Wait_for Multiple_Interrupts_708

The flags included in each function are defined in **Appendix E: Flags for Use with M4K708 Software Tools**.

Get_Interrupt_Count_708

Description	Get_Interrupt_Count_708 returns the total interrupt count for the specified module from the time the module was initialized with Init_Module_708.	
Syntax	Get_Interrupt_Count_708 (int devhandle, unsigned long *pdwInterruptCount)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	pdwInterruptCount	Pointer to an unsigned long which receives the interrupt count
Return Values	ebadhandle	If an invalid handle was specified; should be value returned by Init_Module_708
	egetintcount	If there was a kernel error
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparameter	If input parameter is invalid
	ekernelbadpointer	If output parameter buffer is invalid
	ekerneldevicenotopen	If specified device has not been opened
	0	If successful

InitializeInterrupt_708

Description	InitializeInterrupt_708 may be called to initialize interrupt handling for the given module/card. In general, it is not necessary to call this function since the Wait_for_Interrupt_708 function initializes the interrupt handling automatically when it is first called. However, in certain situations, such as a program in which the Wait_for_Interrupt_708 function is not run in a separate thread but is executed sequentially in the main thread, one may wish to initialize the interrupt handling before calling Wait_for_Interrupt_708. Thus, if an interrupt occurs after the initialization but before the call to Wait_for_Interrupt_708, the latter call will return immediately, reporting the interrupt which occurred previously.	
Syntax	InitializationInterrupt_708 (int devhandle)	
Input Parameters	devhandle	The handle designated by Init_Module_708
Output Parameters	none	
Return Values	ebadhandle	If an invalid handle is specified; should be value returned by Init_Module_708
	egetevenhandle1	If there is an error in kernel function Get_Event_Handle, first part
	egetevenhandle2	If there is an error in kernel function Get_Event_Handle, second part
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If specified device was not opened
	0	If successful

Wait_for_Interrupt_708

Description	Wait_For_Interrupt_708 waits for an interrupt on the module. It suspends control of the calling thread while waiting, and returns control to the thread upon receipt of the interrupt, or upon expiration of the time out. If timeout is set to INFINITE, then the call will return only upon receipt of the interrupt.	
Syntax	Wait_For_Interrupt_708 (int devhandle, unsigned int timeout)	
Example	<p>Since this function suspends execution of the calling thread, it is generally called from a separate thread, to allow the main thread to continue its processing. An example of a thread routine which waits for interrupts and processes them as they come in is as follows:</p> <pre>DWORD InterruptThread(int referenceParam) { while (1) { int status; status = Wait_For_Interrupt_708(devhandle, INFINITE); if (status < 0) { // We don't check for kerneltimeout since we passed // in a timeout value of INFINITE. // All other return values indicate error. // Process error... ExitThread(1); } // Process interrupt... // Check total number of interrupts Get_Interrupt_Count_708(devhandle, &numints); } }</pre>	
Input Parameters	devhandle	The handle designated by Init_Module_708
	timeout	Timeout is specified in milliseconds, or INFINITE
Output Parameters	none	
Return Values	ebadhandle	If an invalid handle is specified; should be value returned by Init_Module_708
	egetevenhandle1	If there is an error in kernel function Get_Event_Handle, first part
	egetevenhandle2	If there is an error in kernel function Get_Event_Handle, second part
	kernelinitmodule	If error initializing kernel related data
	kernelbadparam	If input parameter is invalid
	kerneldevicenotopen	If specified device was not opened
	Successful if <i>either</i> :	
	kerneltimeout	The wait timed out without receiving an interrupt <i>or</i>
	0	If successful

Wait_for Multiple_Interrupts_708

Description	Wait_for_Multiple_Interrupts_708 waits for an interrupt on any of the specified modules. It suspends control of the calling thread while waiting, and returns control to the thread either upon receipt of the interrupt, or upon expiration of the time out. If timeout is set to INFINITE, then the call will return only upon receipt of the interrupt.	
Syntax	Wait_for_Multiple_Interrupts_708 (int nummodules, int *devhandle_array, unsigned int timeout, unsigned long *pdw_Interrupt_Bitfield)	
Input Parameters	nummodules	Number of modules in the devhandle_array
	devhandle_array	An array of module handles
	timeout	Timeout is specified in milliseconds, or INFINITE
Output Parameters	pdw_Interrupt_Bitfield	Pointer to an unsigned long which receives a bit field indicating which of the modules have interrupted (note that more than one module may have interrupted simultaneously). The modules are distributed in the bit field such that the lowest bit corresponds to the first module in the devhandle_array, and so on.
Return Values	egeteventhand1	If there is an error in kernel function Get_Event_Handle, first part
	egeteventhand2	If there is an error in kernel function Get_Event_Handle, second part
	ebadhandle	If an invalid handle specified in the devhandle_array; should be values returned by Init_Module_708.
	ekernelinitmodule	If error initializing kernel related data
	ekernelbadparam	If input parameter is invalid
	ekerneldevicenotopen	If the specified device was not opened
	ekernelbadpointer	If output parameter buffer is invalid
		Successful if <i>either</i> :
	ekerneltimeout	The wait timed out without receiving an interrupt
		<i>or</i>
	0	If successful

Appendix A ARINC 708 Specifications

Display Data Bus Format

Bits	Data Display	Function details	On page
01– 08	Label		
09 – 10	Control/Accept	Table A-2 Control Accept Functions	A-2
11	Slave	1 = Slave 0 = Master (Normal)	
12 – 13	Spare		
14	Turbulence Alert	Automatic sensing of a Turbulence alert has occurred	
15	Weather Alert	Automatic sensing of a reflectivity Weather alert has occurred	
16	AntiClutter	Clutter elimination circuitry is in operation	
17	Sector Scan	Reduced Sector scan is in operation	
18	Stability Limits	Aircraft attitude and /or tilt control exceeds the system's design limits.	
19	Cooling Fault		
20	Display Fault		
21	Calibration (T-R) Fault		
22	Altitude input Fault		
23	Control Fault		
24	Antenna Fault		
25	Transmitter/ receiver Fault		
26	Stabilization On		
27 – 29	Mode	Table A-3 Operating mode	A-2
30 – 36	Tilt	Table A-4 Tilt data	A-2
37 – 42	Gain	Table A-5 Gain data	A-3
43 – 48	Range	Table A-6 Range Data	A-3
49	Spare		
50 – 51	Data Accept	Table A-7 Data accept	A-3
52 – 63	Scan Angle	Table A-8 Scan angle	A-3
64	Spare		
65 – 67	Bin 1		
.	.		
.	.	Table A-9 Weather Condition / Reflectivity Data	A-4
.	.		
1598 – 1600	Bin 512		

Table A-1 Display Data Bus Format

Note: The lowest order bit is referred to as bit 1.

Control Accept Function

Matrix Code	Bit 10	Bit 9	Function
0	0	0	Do not accept control
1	0	1	IND 1 accept control
2	1	0	IND 2 accept control
3	1	1	All INDs accept control

Table A-2 Control Accept Functions

Operating Mode

Matrix Code	Bit 29	Bit 28	Bit 27	Operating Mode
0	0	0	0	Standby
1	0	0	1	Weather [only]
2	0	1	0	Map
3	0	1	1	Contour
4	1	0	0	Test
5	1	0	1	Turbulence [only]
6	1	1	0	Weather & turbulence
7	1	1	1	Reserved [Calibration annunciation]

Table A-3 Operating mode

Note: Weather (only) Reflectivity (Weather) only data should be transmitted on all azimuth addresses.

Turbulence (only) Turbulence only data should be transmitted on all azimuth addresses.

Weather & turbulence Turbulence data combined with reflectivity data is allowed as a means to transmit both weather only and weather plus turbulence words when Weather & turbulence mode is selected.

Tilt Data

Bit	Tilt in degrees
36	-16
35	+8
34	+4
33	+2
32	+1
31	+0.5
30	+0.25

Table A-4 Tilt data

Note: TWO's complement tilt

Gain Data

Bit	42	41	40	39	38	37	
	1	1	1	1	1	1	Cal
	0	0	0	0	0	0	Max
	0	0	0	1	0	1	-5
	0	0	1	0	1	1	-11
	1	1	1	1	1	0	-62

Table A-5 Gain data**Range Data**

Bit	48	47	46	45	44	43	
	0	0	0	0	0	1	5 NM
	0	0	0	0	1	0	10
	0	0	0	1	0	0	20
	0	0	1	0	0	0	40
	0	1	0	0	0	0	80
	1	0	0	0	0	0	160
	1	1	1	1	1	1	315
	0	0	0	0	0	0	320

Table A-6 Range Data**Data Accept**

Bit	51	50	Function
	0	0	Do not accept data
	0	1	Accept data 1
	1	0	Accept data 2
	1	1	Accept any data

Table A-7 Data accept**Scan Angle**

Bit	Angle (in degrees)	Bit	Angle (in degrees)
63	180	57	2.8125
62	90	56	1.40625
61	45	55	0.703125
60	22.5	54	0.3415625
59	11.25	53	0.17578125
58	5.625	52	0.087890625

Table A-8 Scan angle

Weather Conditions/Reflectivity Data

Matrix code [Pixel Value 3 bits]	Weather Condition	Bin 1		
		Bit 67	Bit 66	Bit 65
0	No precipitation [$< Z_2$]	0	0	0
1	Light precipitation [$Z_2 - Z_3$]	0	0	1
2	Moderate precipitation [$Z_3 - Z_4$]	0	1	0
3	Heavy precipitation [Z_4 to Z_5]	0	1	1
4	Very heavy precipitation [$> Z_5$]	1	0	0
5	Reserved ¹	1	0	1
6	Medium turbulence	1	1	0
7	Heavy turbulence	1	1	1

Table A-9 Weather Condition / Reflectivity Data

1. Out of Calibration Indication

Appendix B EXC-4000PCI Boards: Installation Instructions

Appendix B explains the procedure for installing *M4K708* for the:

- *M4K708* module on the EXC-4000PCI
- *M4K708* module on the EXC-c4000PCI

M4K708 Software Tools is for several different operating systems. Appendix B explains the procedure for installing it on the following systems.

- Windows 9x/*ME*
- Windows NT4
- Windows 2000/XP

Warning: *Whenever you handle an EXC-4000PCI board, wear a suitably grounded electrostatic discharge wrist strap.*

Windows 9x /ME Procedures

The Excalibur Installation CD contains the files for:

- *PCI Hardware Installation for Windows 9x/ME*
- *M4K708 Software Tools*

To install an EXC-4000PCI board on a Windows 9x system:

1. Insert the board into an available PCI slot in your computer
2. Add *M4K708 Software Tools* to your Windows 9x system.

To verify that the board was installed correctly, run the test programs included on the *Excalibur Installation CD*.

To install the Excalibur EXC-4000PCI board

1. Make sure the computer is turned off. Insert the board into one of the available slots. For more information see the Installation section in the hardware *User's Manual*.
2. Turn on the computer and wait several moments while Windows 9x/*ME* boots up.
3. The message **Building driver information data** may or may not appear. After several seconds, the message **New Hardware Found** is displayed. Next, the **Update Device Driver Wizard** is displayed.

Note: If the **Update Device Driver Wizard** is not displayed, and you are upgrading from a previous version of the PCI Win 9x/ME Hardware Installation, follow these steps to invoke the **Update Device Driver Wizard**. Right-click **My Computer**, then click **Properties | Device Manager | Excalibur PCI Cards | Excalibur 4000PCI Card | Properties | Driver | Update Driver**.

4. Insert the *Excalibur Installation CD* in the drive and follow the on-screen instructions.
5. When the following message appears: **Windows found the following updated driver for this device: Excalibur EXC-4000 card**, click **Finish**.
6. Board installation is completed. If prompted to reboot the computer, do so now. Next, continue with board verification below.

To verify board installation:

1. Make certain the Excalibur EXC-4000PCI board is in place in the computer.
2. Right-click **My Computer**. Select **Properties**. The **System Properties** dialog box appears.
3. In the **System Properties** dialog box, click the **Device Manager** tab.
4. Double-click **Excalibur PCI Card**. Verify that the Excalibur EXC-4000PCI board is listed next to a gray diamond-shaped icon.

Board installation verification is successful.

Note: If you see an exclamation point (!) superimposed on the gray diamond, this indicates that the board is not properly installed. Check the following:

- There are not enough memory resources available in the system, free up more memory or IRQs.
- That the computer is Plug and Play compatible. Many computers claim to be “Plug and Play” but are not fully compatible with the Plug and Play specification.

To Add *M4K708 Software Tools* to Windows 9x/ME Systems

Note: If there is already a previous version of *Software Tools* for the same module installed on the computer, the new version will overwrite it. We recommend that you first uninstall the previous version by selecting **Start | Settings | Control Panel | Add/Remove Programs**. If you want to save the earlier version, you can choose to install the new version to a different directory when the Install Wizard asks to which directory to install the software.

1. Insert the *Excalibur Installation CD* in the drive, click **Install Drivers, Applications, Utilities**.
2. Follow the on-screen instructions to select the software that matches your product.
3. When the **Excalibur Configuration Utility (ExcConfig)** screen appears, double-click the **Type** field. Select **4000PCI**.
4. Leave the **Auto** values and click **Save**.

Note: Remember the device number; it is the parameter for the `Init_Module_708` function.

Running test programs

Excalibur provides test programs to verify that the board is operating properly. The source code is provided with the test programs as a guide to develop your own applications.

To run the test programs in *M4K708 Software Tools*, the EXC-4000PCI must be linked up to a loopback cable. For details refer to the section *Mechanical and Electrical Specification* in the *M4K708 Module User's Manual*.

Go to **Start | Programs | [Product Name]**, to run the test programs.

Windows NT4 Procedures

The *Excalibur Installation CD* contains the files for:

- *M4K708 Software Tools*

To install an EXC-4000PCI board on a Windows NT4 system:

1. Insert the board into an available PCI slot in the computer.
2. Add *M4K708 Software Tools*
3. Reboot the computer
4. To verify that the board was installed correctly, run the test programs that are included on the *Excalibur Installation CD*

To install the Excalibur EXC-4000PCI board

1. Make sure the computer is turned off.
2. Insert the board into one of the available slots.

For more information, see the section “Installation” in the hardware *[Product Name]: User’s Manual*.

To add *M4K708 Software Tools* to Windows NT4 systems

Note: If there is already a previous version of *Software Tools* for the same module installed on the computer, the new version will overwrite it. We recommend that you first uninstall the previous version by selecting **Start | Settings | Control Panel | Add/Remove Programs**. If you want to save the earlier version, you can choose to install the new version to a different directory when the Install Wizard asks to which directory to install the software.

1. Insert the Excalibur Installation CD in the drive, click **Install Drivers, Applications, Utilities**.
2. Follow the on-screen instructions to select the software that matches your product.
3. When the **Excalibur Configuration Utility (ExcConfig)** screen appears, double-click the Type field. Select **4000PCI**.
4. Leave the **Auto** values and click **Save**.

Note: Remember the device number; it is the parameter for the `Init_Module_708` function.

5. Reboot the computer at the end of the installation procedure.

The EXC-4000PCI board is now ready to run.

Running test programs

Excalibur provides test programs to verify that the board is operating properly. The source code is provided with the test programs as a guide to develop your own applications.

To run the test programs in *M4K708 Software Tools*, the EXC-4000PCI must be linked up to a loopback cable. For details refer to the section *Mechanical and Electrical Specification* in the *M4K708 Module User’s Manual*.

Go to **Start | Programs | [Product Name]**, to run the test programs.

Windows 2000/XP Procedures

The *Excalibur Installation CD* contains the files for:

- *PCI Hardware Installation for Windows 2000/XP*
- *M4K708 Software Tools*

To install an EXC-4000PCI board on a Windows 2000/XP system:

1. Insert the board into an available PCI slot in your computer
2. Add *M4K708 Software Tools* to your Windows 2000/XP system.

To verify that the board was installed correctly, run the test programs included on the *Excalibur Installation CD*.

To install the Excalibur EXC-4000PCI Board:

1. Make sure the computer is turned off. Insert the board into one of the available slots. For more information see the Installation section in the hardware *User's Manual*.
2. Turn on the computer and wait several moments while Windows 2000/XP boots up.
3. The message **Building driver information data** may or may not appear. After several seconds, the message **New Hardware Found** is displayed. Next, the **Update Device Driver Wizard** is displayed.

Note: If the **Update Device Driver Wizard** is not displayed, and you are upgrading from a previous version of the PCI Windows Hardware Installation, follow these steps to invoke the **Update Device Driver Wizard**. Right-click **My Computer**, then click **Hardware | Device Manager | Excalibur PCI Cards | Excalibur 4000PCI card**. Double-click and select **Driver | Update Drivers**.

4. Insert the *Excalibur Installation CD* in the drive and follow the on-screen instructions.
5. When the following message appears: **Windows found the following updated driver for this device: Excalibur EXC-4000 card**, click **Finish**.
6. Board installation is completed. If prompted to reboot the computer, do so now. Next, continue with board verification below.

To verify board installation:

1. Make certain the Excalibur EXC-4000PCI board is in place in the computer.
2. Right-click **My Computer | Properties**. The System Properties dialog box appears.
3. In the System Properties dialog box, click **Hardware | Device Manager**.
4. Double-click **Excalibur PCI Board**. Verify that the Excalibur PCI Board is listed next to a gray diamond-shaped icon.

Note: If an exclamation point (!) appears, superimposed on the gray diamond, this indicates that the board is not properly installed. Check that there are enough memory resources available in the system. Free up more memory or IRQs.

The board installation verification is successful.

To add M4K708 Software Tools under Windows 2000/XP

Note: If there is already a previous version of *Software Tools* for the same module installed on the computer, the new version will overwrite it. We recommend that you first uninstall the previous version by selecting **Start | Settings | Control Panel | Add/Remove Programs**. If you want to save the earlier version, you can choose to install the new version to a different directory when the Install Wizard asks to which directory to install the software.

1. Insert the Excalibur Installation CD in the drive, click **Install Drivers, Applications, Utilities**. Follow the on-screen instructions to select the software that matches your product.
2. When the **Excalibur Configuration Utility (ExcConfig)** screen appears, double-click the **Type** field. Select **4000PCI**.
3. Leave the **Auto** values and click **Save**.

Note: Remember the device number; it is the parameter for the `Init_Module_708` function.

The EXC-4000PCI board is now ready to run.

Running test programs

Excalibur provides test programs to verify that the board is operating properly. The source code is provided with the test programs as a guide to develop your own applications.

To run the test programs in *M4K708 Software Tools*, the EXC-4000PCI must be linked up to a loopback cable. For details refer to the section *Mechanical and Electrical Specification* in the *M4K708 Module User's Manual*.

Go to **Start | Programs | [Product Name]**, to run the test programs.

Appendix C **EXC-4000VME Boards: Installation Instructions for PCI-MXI-2 Systems**

Appendix C explains the procedure for installing the *M4K708 Software Tools* for the Excalibur EXC-4000VME and EXC-4000VXI boards under a Windows operating system.

Installation of the EXC-4000VME board on a Windows system is accomplished by determining the board's logical address, setting the DIP switch on the board, and installing *M4K708 Software Tools*. To verify board installation, run the test-programs that are included on the *Excalibur Installation CD*.

All the files needed to run *M4K708* on Windows operating systems are on the *Excalibur Installation CD*.

Note: *M4K708 Software Tools* for VME boards were written for VISA standard.

To install the EXC-4000VME board:

1. Ensure the National Instruments PCI-MXI-2 system is installed correctly.
2. Before installing the Excalibur board, it is very important to determine the board's logical address. The board requires a 1MB area of memory. Choose a logical address that does not conflict with any other devices in your system. The board is set at default address 80H (128 Dec.).

Warning: If a logical address is already in use and it is also used for the EXC-4000VME, the board will not function properly.

3. Set the Board Logical Address DIP switch (SW1) according to the logical address chosen. See the section on DIP Switch Settings in the EXC-4000VME hardware *User's Manual*.
4. Turn on your VME and PC computers. Run the two programs that establish the connection to the VME (VXIINIT, the hardware initialization program, and Resman, the resources manager program).

Note: Later versions of the National Instruments PCI-MXI-2 may not require running VXIINIT.

Appendix D Multiple Board Support for EXC-4000 Carrier Boards

EXC-4000PCI and EXC-4000cPCI Carrier Boards

M4K708 Software Tools supports the use of up to four PCI and cPCI boards simultaneously.

To use multiple boards:

1. Each board must be set for a unique ID. The ID of a board is set via the SW1 DIP switch. To set the ID of the board set the jumpers as follows:

Board ID	SW1 Switch contact			
	1	2	3	4
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1

Set DIP switch SW1 to a unique ID by setting the switch contacts *open* or *off* to represent logic '1'; and closed or on to represent logic '0'.

2. In the **ExcConfig** utility program, create a separate device number for each board. For each board enter the appropriate values in the Excalibur Configuration Utility Screen, as described in the table below.

Name of field	Enter this value
Type	Select 4000PCI from the drop-down list
Unique Identifier	Set to the unique ID configured above in Step 1.
Memory	Set to automatic setting
Interrupt Setup	Set to automatic setting
I/O ports	Set to automatic setting

EXC-4000VME and EXC-4000VXI Boards

M4K708 Software Tools supports the simultaneous use of up to eight *M4K708* modules on a single VME or VXI board. The number of boards supported depends on the user's system.

A unique Logical Address must be set for each board. Use DIP switch SW1 to set the board's Logical Address.

Examples of Logical Address Switch (SW1) Settings:

		MSB Logical Address Switch (SW1) LSB							
'1'	'1'	1	2	3	4	5	6	7	8
A15	A14	A13	A12	A11	A10	A9	A8	A7	A6
Logical Address		Switch Settings							
Hex	Dec								
1	1	0	0	0	0	0	0	0	1
20	32	0	0	1	0	0	0	0	0
80	128	1	0	0	0	0	0	0	0
81	129	1	0	0	0	0	0	0	1
C0	192	1	1	0	0	0	0	0	0
FF	255	1	1	1	1	1	1	1	1

Example: For a logical address of C0 (H) [=A16 Address F000 (H)], set position 1 and 2 to OFF or Open and all other switches to ON or Closed.

Switch ON or Closed = logic 0 at switch position

Switch OFF or Open = logic 1 at switch position

- Note:**
1. Numbers indicate switch positions.
 2. Address lines A15 and A14 are always decoded as '1'.
 3. Address lines A5–A0 are always decoded as '0'.

Appendix E Flags for Use with *M4K708 Software Tools*

Flags are grouped according to the functions in which they are used. Some flags are used in more than one function, and they are duplicated in each section for clarity. Most flags are input parameters. Others are listed for the convenience of the programmer.

Note: Always use flags where provided, rather than the value associated with it, since values may change. For example, use `SIMULATE` with `Init_Module` rather than `0xFFFF`.

The flags are grouped by function.

Init_Module

<code>SIMULATE</code>	<code>0xFFFF</code>	Test drivers without a module present
<code>EXC_4000PCI</code>		If only one board is used, the define value <code>EXC_4000PCI</code> can be used instead of a device number

Create/ParseControlData_708

```
typedef struct
{
    WORD    label; //8 bits
    WORD    controlAccept; //2
    BOOL    slave;
    BOOL    turbulenceAlert;
    BOOL    weatherAlert;
    BOOL    antiClutter;
    BOOL    sectorScan;
    BOOL    stabilityLimits;
    BOOL    coolingFault
    BOOL    displayFault;
    BOOL    calibrationFault;
    BOOL    attitudeFault;
    BOOL    controlFault;
    BOOL    antennaFault;
    BOOL    txRcvFault;
    BOOL    stabilization;
    WORD    operatingMode; //3
    WORD    tilt; //7
    WORD    gain; //6
    WORD    range; //6
    WORD    dataAccept; //2
    WORD    scanAngle; //12
}t_controlStruct;
```

StartTransmit_708

<code>DUR_ONESHOT</code>	<code>0</code>	To send out one ARINC 708 word
<code>DUR_CONTINUOUS</code>	<code>1</code>	To continuously transmit until buffer empty
<code>DUR_RETRANSMIT</code>	<code>2</code>	To transmit contents of buffer again and again until stopped - data <i>cannot</i> be written to the buffer

GetStatus_708

ERROR_STATUS	1	Error occurred on channel
TXRX_STATUS	2	The number of ARINC 708 words set in SetEventFrequency_708 was transmitted/received
NO_STATUS	0	No channel status bits set

ClearStatus_708

ERROR_STATUS	1	Clear error status bit
TXRX_STATUS	2	Clear TXRX status bit
ALL_STATUS	3	Clear all status bits

SetInterrupt_708

ERROR_INTERRUPT	1	Interrupt when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition
TXRX_INTERRUPT	2	Interrupt after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708.
NO_INTERRUPT	0	Disable Interrupts

SetTrigger_708

ERROR_TRIGGER	1	Trigger when channel is transmitting in CONTINUOUS or RETRANSMIT mode and buffer is empty or when channel is receiving and buffer is full - overrun condition
TXRX_TRIGGER	2	Trigger after each time the specified number of ARINC 708 words is transmitted/received. The number is set by SetEventFrequency_708.
NO_TRIGGER	0	Disable output triggering

SetLoopback_708

DISABLE	0	Disable loopback mode
ENABLE	1	Set up internal loopback mode

ReadWord_708

INVALID_708WORD	0	Manchester error
VALID_708WORD	1	Valid ARINC 708 word

Module types for EXC-4000 carrier boards

EXC4000_MODTYPE_SERIAL	2	A Serial module is present
EXC4000_MODTYPE_MCH	3	A MCH module is present
EXC4000_MODTYPE_RTX	4	An RTx module is present
EXC4000_MODTYPE_PX	5	A Px module is present
EXC4000_MODTYPE_MMSI	6	A MMSI module is present
EXC4000_MODTYPE_708	7	A 708 module is present
EXC4000_MODTYPE_MA	8	A MicroAce module is present
EXC4000_MODTYPE_H009	9	A H009 module is present
EXC4000_MODTYPE_DIO	0xd	A Discrete module is present
EXC4000_MODTYPE_NONE	0x1F	No module present

Appendix F *M4K708 Software Tools Library*

Appendix F includes a list of the files in the Excalibur *M4K708 Software Tools* needed to write user-defined applications. The files are divided into three categories:

Source code and Header files for the *M4K708 Software Tools* functions. Header files should be included in application programs as needed.

File Extension	Description
*.c	source code
*.h	header file

DLL and associated *.lib files

File Extension	Description
*.dll	Borland compiler DLL
*MS.dll	Microsoft compiler DLL
*.lib	Index file used to create applications using Borland DLL functions
*MS.dll	Index file used to create applications using Microsoft DLL functions

Demo Programs are examples of programs using *M4K708 Software Tools*. They can be used as a basis for user-defined programs. Demo programs include the following types of files.

File Extension	Description
*.c, *.h	Demo source code
*.ide	Borland demo project files
*.exe	Borland demo executable files
*.dsp	Microsoft demo project files
*.dsw	
*MS.exe	Microsoft demo executable files

	File Name	Description
Source Code Files	<code>config_708</code>	Functions for configuring <i>M4K708</i> channels
	<code>comm_708</code>	Functions for communication over a <i>M4K708</i> module
	<code>deviceio_708</code>	Functions for interaction with kernel driver for Windows operating systems
	<code>error_708</code>	function for returning error messages
	<code>EXC4000</code>	For <i>M4K708</i> modules on PCI carrier boards - functions for extracting information associated with the carrier board.
	<code>EXCv4000</code>	For <i>M4K708</i> modules on VME/XVI carrier boards - functions for extracting information associated with the carrier board.
	<code>init_708</code>	Initialization and Release module functions
Source Header files	<code>config_708</code>	Header file for configuration functions
	<code>comm_708</code>	Header file for communication functions
	<code>deviceio_708</code>	Header file for interaction with kernel driver
	<code>error_devio</code>	Header file containing error codes for the Excalibur kernel drivers
	<code>error_708</code>	Header file containing error message codes
	<code>EXC4000</code>	For <i>M4K708</i> on PCI carrier boards - Header file containing prototypes for functions associated with the carrier board
	<code>EXCv4000</code>	For <i>M4K708</i> on VME/VXI carrier boards - Header file containing prototypes for functions associated with the carrier board.
	<code>Excysysio</code>	Header file which defines control codes in kernel drivers and defines strings for module names for use in <code>Init_Module_708</code> calls to kernel drivers
	<code>Flags_708</code>	Header file containing flags for <i>M4K708</i> , for applications
	<code>Instance_708</code>	Header file for global module structure
	<code>proto_708</code>	Header file, prototypes of all functions. This will include all the header files needed for applications
	<code>708Incl</code>	Header file, include for recompiling the 708 <code>d11</code> code, not for applications
Demo Programs	<code>Reg_708</code>	Header file containing data structures
	<code>demo_708_int</code>	Interrupt demo
	<code>demo_708</code>	Demo illustrating functions of <i>M4K708 Software Tools</i>
	<code>demo_708_loop back</code>	Demo illustrating loopback functions

DLL and *.LIB files	File Name	Description	
	The table below shows the name of the DLL file and its corresponding LIB file for each module under the Borland and Microsoft compilers		
	Module	Borland	Microsoft
	Px	PX	pxms
	MCH	MCH	mchms
	RTx	RTX	rtxms
	Discrete	M4Kdio	M4Kdioms
	Serial	excser	excserms
	H009	M4KH009	M4KH009ms
	708	exc708	exc708ms
	MMSI	m4kmmsi	m4kmmsims

Appendix G Code Index

M4K708 Software Tools is a set of C language functions designed to aid users of the *M4K708* module to write test programs. Below is an alphabetical listing of all the functions and the name of the *Software Tools* file which contains its programming code.

Driver Functions	Code File Name (*.c)
ClearStatus_708	comm_708
Get_4000Module_Type for PCI boards	EXC4000
Get_4000Module_Type for VME/VXI boards	EXCv4000
Get_Error_String_708	error_708
Get_Interrupt_Count_708	deviceio_708
GetHWRev_708	init_708
GetModuleTimetag_708	init_708
GetPixel_708	comm_708
GetStatus_708	comm_708
Init_Module_708	init_708
InitializeInterrupt_708	deviceio_708
ModuleTimetagReset_708	init_708
NumberWordsInBuffer_708	comm_708
ReadWord_708	comm_708
Release_Module_708	init_708
Select_Time_Tag_Source_4000	EXC4000
SetControlData_708	comm_708
SetEventFrequency_708	config_708
SetInterrupt_708	config_708
SetLoopback_708	init_708
SetPixel_708	comm_708
SetTransmitInterval_708	config_708
SetTrigger_708	config_708
SetupReceiveChannel_708	config_708
SetupTransmitChannel_708	config_708
StartReceive_708	comm_708
StartTransmit_708	comm_708
Stop_708	comm_708
Wait_for_Interrupt_708	deviceio_708
Wait_for Multiple Interrupts_708	deviceio_708
WriteWord_708	comm_708

Appendix H Error Messages

All functions for *M4K708 Software Tools* are written as C functions, i.e., they return values. A negative value signifies an error. Full error messages may be printed using the `Get_Error_String_708` function. Below is a list of all *Software Tools* error messages, the negative value of each, and an explanation of the error

Error	Value	Explanation
<code>einval</code>	-2	Illegal value used as an input
<code>sim_no_mem</code>	-5	No memory for simulation
<code>etimeoutreset</code>	-26	Timed out waiting for reset
<code>ewrngmodule</code>	-27	Module specified on EXC-4000 board is not a <i>M4K708</i> module
<code>enomodule</code>	-28	No EXC-4000 module present at the specified location
<code>ebadhandle</code>	-33	Invalid handle specified; should be value returned by <code>Init_Module_708</code>
<code>eboardtoomany</code>	-36	Too many modules initialized
<code>noirqset</code>	-53	No interrupt allocated.
<code>einvalchan</code>	-200	Tried to set channel to illegal value
<code>ebadchanhandle</code>	-203	Invalid handle specified, should be value returned by channel setup routine
<code>echantype</code>	-204	Function invalid for this channel type
<code>enoxmword</code>	-205	No room to transmit ARINC 708 word
<code>enorcvword</code>	-206	No ARINC 708 word received
<code>ebadformat</code>	-207	No proper ARINC 708 word found in receive buffer
<code>erunning</code>	-208	Channel already running
<code>eoneshot</code>	-209	Cannot write to buffer when channel running in ONESHOT mode
<code>eretransmit</code>	-210	Cannot write to buffer when channel running in RETRANSMIT mode

For EXC-4000PCI boards only

Error Code	Value	Explanation
eopenkernel	-1001	Cannot open kernel device; check Excalibur Configuration Utility settings
kernelcantmap	-1002	Kernel driver cannot map memory
ereleventhandle	-1003	Error in kernel Release_Event_Handle
egetintcount	-1004	Error in kernel Get_Interrupt_Count
egetchintcount	-1005	Error in kernel Get_Channel_Interrupt_Count
egetintchannels	-1006	Error in kernel Get_Interrupt_Channels
ewriteiobyte	-1007	Error in kernel writeiobyte
ereadiobyte	-1008	Error in kernel readiobyte
egeteventhand1	-1009	Error in kernel Get_Event_Handle, first part
egeteventhand2	-1010	Error in kernel Get_Event_Handle, second part
eopenscman	-1011	Error in openscmanager in startkerneldriver
eopenservicet	-1012	Error in openservice in startkerneldriver
estartservice	-1013	Error in startservice in startkerneldriver
eopenscmanp	-1014	Error in openscmanager in stopkerneldriver
eopenservicep	-1015	Error in openservice in stopkerneldriver
econtrolservice	-1016	Error in controlservice in stopkerneldriver
eunmapmem	-1017	Error in kernel unmapmemory
egetirq	-1018	Error in Get_IRQ_Number
eallocresources	-1019	Error allocating resources. See readme.pdf for details on resource allocation problems.
egetramsize	-1020	Error in kernel getramsize
kernelwriteattrib	-1021	Error in kernel write attribute
kernelreadattrib	-1022	Kernel read attribute error
kernelfrontdesk	-1023	Kernel frontdesk error
kerneloscheck	-1024	Kernel Oscheck error
kernelfrontdeskload	-1025	Kernel frontdeskload error
kerneliswin2000compatible	-1026	Kernel iswin2000compatible error
kernelbankramsize	-1027	Kernel banksize error
kernelgetcardtype	-1028	Kernel getcardtype error
emodnum	-1029	Invalid module number specified

Error Code	Value	Explanation
regnotset	-1030	Board not configured. Reboot after ExcConfig is run and board is in slot
ekernelbankphysaddr	-1031	Error in GetBankPhysAddress
ekernelclosedevice	-1032	Error in CloseKernelDrive
ekerneldevicenotopen	-1034	Kernel error: device is not opened
ekernelinitmodule	-1035	Kernel initialization error
ekernelbadparam	-1036	Kernel error: bad input parameter
ekernelbadpointer	-1037	Kernel error: invalid pointer to output buffer
ekerneltimeout	-1038	Wait for Interrupt function returned with timeout
ekernelnotwin2000	-1039	Operating System is not Windows 2000
erquestnotification	-1040	Request_Interrupt_Notification error
ekernelnot4000Card	-1041	Designated Board is not an EXC-4000 carrier board
enotimersirig	-1042	Timers and IrigB not supported on this version of EXC-4000 board
eclocksource	-1059	If an invalid clock source was specified
eparmglobalreset	-1062	Illegal parameter used for <code>globalreset_flag</code> in StartTimer
etimernotrunning	-1063	Timer not running when ResetWatchdogTimer was called; did nothing
etimerrunning	-1064	Timer already running when StartTimer was called; did nothing
eparmreload	-1065	Illegal parameter used for <code>reload_flag</code> in StartTimer
eparminterrupt	-1066	Illegal parameter used for <code>interrupt_flag</code> in StartTimer
ebaddevhandle	-1067	Invalid handle specified. Use value returned by Init_Timers
edevtoomany	-1068	Init_Timers called for too many boards
einvalidOS	-1069	If an invalid operating system is used

For EXC-4000VME/VXI boards only

Error Code	Value	Explanation
eviclosedev	-1050	Error in ViClose device
evicloserm	-1051	Error in ViClose Default RM
eopendefaultrm	-1052	Error in ViOpenDefault RM
eviopen	-1053	Error in ViOpen
evimapaddress	-1054	Error in viMapAddress
evicommand	-1055	Error in VISA command
einstallhandler	-1056	Error in VISA viInstallHandler
eenableevent	-1057	Error in VISA viEnableEvent
euninstallhandler	-1058	Error in VISA viUninstallHandler
eclocksource	-1059	If an invalid clock source was specified
edevnum	-1060	If a device number greater than 255 was used
einstr	-1061	If a device was not successfully initialized by Init_Module_708

Functions Index

C

ClearStatus_708, 4-1

G

Get_4000Module_Type for PCI boards, 1-6

Get_4000Module_Type for VME/VXI boards, 1-7

Get_Error_String_708, 2-6

Get_Interrupt_Count_708, 5-2

GetControlData_708, 4-7

GetData_708, 4-6

GetHWRev_708, 2-4

GetModuleTimetag_708, 2-5

GetPixel_708, 4-6

GetStatus_708, 4-2

I

Init_Module_708, 2-2

InitializeInterrupt_708, 5-3

M

ModuleTimetagReset_708, 2-5

N

NumberWordsInBuffer_708, 4-2

R

ReadWord_708, 4-3

Release_Module_708, 2-3

S

Select_Time_Tag_Source_4000, 1-8

SetControlData_708, 4-7

SetData_708, 4-6

SetEventFrequency_708, 3-4

SetInterrupt_708, 3-3

SetLoopback_708, 2-4

SetPixel_708, 4-7

SetTransmitInterval_708, 3-3

SetTrigger_708, 3-4

SetupReceiveChannel_708, 3-2

SetupTransmitChannel_708, 3-2

StartReceive_708, 4-4

StartTransmit_708, 4-4

Stop_708, 4-5

W

Wait_For_Interrupt_708, 5-4

Wait_for_Multiple_Interrupts_708, 5-5

WriteWord_708, 4-5

The information contained in this document is believed to be accurate. However, no responsibility is assumed by Excalibur Systems, Inc. for its use and no license or rights are granted by implication or otherwise in connection therewith. Specifications are subject to change without notice.

January 2006, Rev A-2